


KitchenAid®

ELECTRIC RANGE

MODELS:

KSEG700EBS7 (Black Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Endcap	26	7101P485-60	Screw, Anti-Tip Kit
	W11435572	Quick Start Guide		W10913412	Black (Left)	27	W11379947	Bracket, Anti-Tip
	W11509603	Owners Manual		W10913413	Black (Right)	28	W10854253	Bumper
	W11326876	Tech Sheet	16		Console	29	W10759325	Assembly, Display
2	W11600012	Spring, Element		W10861018	Black	30	7201P077-60	Gasket, Infinite Switch
3	3196178	Screw	17	W10578768	Switch, Infinite (Right Rear)	31		Console, Lower Panel
4		Cooktop	18	W10437094	Switch, Infinite (Right Front and Left Rear)		W10860957	Black
	W10536295	Black				32		Bezel
5	W11318371	Element (3000W) (Left Front)	19		Knob		W10663809	Stainless
6	W10248261	Element (1200W) (Right Rear)		W10823543	Stainless (Right Rear)	33	W10558372	Bracket, Control
7	W10251108	Element (3200W) (Right Front)		W10823541	Stainless (Left Rear)	34	W10437097	Switch, Infinite (Left Front)
8	W10342780	Element (1300W) (Left Rear)		W10823538	Stainless (Right Front)	35	W11355689	Keypad Shield
9	W10799048	Element, Warm Zone (Center Rear)		W10823536	Stainless (Left Front)	36	W10882900	Gasket
10	W11175271	Bracket, Radiant	20	W10598048	Bracket, Console (Center)			FOLLOWING PARTS NOT ILLUSTRATED
11	W10536275	Pan, Radiant					W11454505	Harness, Main
12	W10162253	Brace, Corner (Left)	21	W10759276	Control, MRC2		W10575120	Harness, Keypad
	W10162252	Brace, Corner (Right)	22	W10612719	Gasket, Console and Cooktop		W11172426	Harness, Display
13	W10289169	Support, Cooktop (Right)	23		Vent, Trim Top		W11172417	Harness, Console
	W10289170	Support, Cooktop (Left)		W10636528	Black		W10664316	Clip, Harness (Cooktop)
14	3196173	Screw	24	3196068	Lens, Indicator		313438	Clip, Harness
			25	W10555923	Bracket, User Interface		W11134658	Harness, Cooktop
							W10653092	Suppressor


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	22	W11034869	Screw	44	W11117035	Shield, Wire
2	3196560	Screw	23	3196178	Screw	45	W10162241	Channel, Rear
3		Panel, Side	24	W11634772	Light Assembly	46	W10162248	Cover, Wire
	W10162245	Black	25	W10571723	Bulb, Halogen 40 Watts	47	W11379354	Cover, Back
4	3400029	Nut	26	3400016	Screw	48	W10686408	Kit, Reservoir (Steam Rack)
5	W11491752	Gasket, Door	27	W10586204	Sensor	49	W10554007	Rack, Steam
6	W10544952	Element, Broil	28	3196169	Screw	50	W10554006	Rack, Maximum Capacity
7	W10774342	Element, Bake	29	W10655441	Shield, Power Cord	51	W10914589	Counterweight
8	W10362924	Screw	30	W10031780	Screw	52	W11620269	Bracket, Front Frame
9	W11122085	Assembly, Flue	31	W10273192	Rod, Door Switch	53	W11510561	Barrier Rail, Rubber (Front Left)
10	W10289168	Box, Burner SI	32	9758701	Spacer, Door		W11510562	Barrier Rail, Rubber (Front Right)
11	W10341186	Front Foot Assembly	33	W10774446	Bottom, Oven			FOLLOWING PARTS NOT ILLUSTRATED
12	W10067840	Screw	34	W11511828	Switch, Door			
13	W10541959	Shield, Bake	35	W10281322	Kit, Bare Wire Adapter Block			
14	W10137382	Clip, Panel	36	W10554005	Rack, Heavy Duty			
15	W10390008	Base Rail Assembly (Left)	37	W11353932	Convection Assembly		W10289173	Insulation, Wrap
	W10390007	Base Rail Assembly (Right)	38	W10346153	Baffle, Full Convection		W10575374	Insulation, Bottom
16	W10058460	Foot, Leveling	39	W10273002	Bracket, Oven Support		4820F015-59	Insulation, Strap
17	3196548	Fuse, Thermal	40	W11379357	Bake Pan		W10162240	Insulation, Back
18	3196172	Screw	41	W10162255	Duct, Cover		7111P017-60	Clamp, Wire
19	W10035900	Support, Oven Bottom	42	W10162254	Duct, Cooling			
20	3186034	Bracket, Service	43	W11467246	Cooling Fan			
21	W10245259	Block, Terminal						

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door Handle
	W11669501	Stainless
2	9780274	Screw
3	W10518672	Badge
4	W10826568	Liner, Door
5	W10031790	Screw
6	W11223202	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10885519	Hinge, Door (Active)
8		Assembly, Outer Door
	W10861021	Black
9	W10541911	Bracket, Glass Upper Handle
10	W10327235	Screw
11	W10813140	Rail, Horizontal Support

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10031780	Screw
13	8533988	Screw
14	W10813139	Rail, Vertical Support
15		Scoop, Door
	W10613791	Black
16	W11379948	Glass Spacer
17	W10319024	Washer, Door
18	W11440161	Bottom, Door Cover

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Drawer	5	W10441804	Slide, Drawer (Left)	6	3196169	Screw
	W11669501	Stainless		W10441805	Slide, Drawer (Right)	7	3823F017-45	Spacer, Handle
2	W10688022	Drawer, Storage						
3	W10318026	Bracket, Mounting						
4		Panel, Drawer Front						
	W10860958	Black						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS AND POLISHES
	31605	Kit, Cooktop Care
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10432539	Griddle
	W10432545	Kit, Grill
		TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit and Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint