

Robot Charging

1. Manual Charging

To manually charge the robot, connect the charging cable to the robot's charging port. Ensure a secure connection between the charging port and the cable. If the connection is successful, the robot will indicate that it is charging.




2. Automatic Charging

The robot supports automatic charging function, which requires optional installation of a docking station or a charging station, and deployment according to the instructions of the selected equipment. After deployment, the robot can achieve full-process automatic recharging by docking with the charging station.



3. Charging interface



Charging in progress