


# AMANA®

## **GAS RANGE**

### **MODELS:**

AGG222VDW6 (White)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Grate, Burner	16	W11561789	Z Bracket, Manifold
	W11603122	Installation Instructions		W10180089	Black			FOLLOWING PARTS NOT ILLUSTRATED
	W11508818	Use and Care Guide	7	98004722	Clip, Cooktop			
	W11565447	Sheet, Tech	8	W10207167	Bumper, Cooktop	W10914404		Harness, Main
	98007130	Tips, Safe Cooking (English)	9	W10493726	Screw	W11562248		Harness, Switch
2		Cooktop	10	98012912	Support, Oven Burner	6610473		Wire, Ground
	W10179560	White	11	98004722	Clip, Cooktop	3196696		Clip-Harness
3		Panel, Manifold	12	W11509664	Bracket, Support Left	98004294		Wire Tie, Insulation
	W10225327	White		W11509665	Bracket, Support Right	98015022		Bushing, Snap
4		Knob, Burner	13		Switch, Rocker	3391018		Tie, Cable
	W11511810	White		W11531408	White			
5		Knob, Thermostat	14	W10243396	Burner, Standard			
	W10483330	White	15		Cap, Burner			
				98017461	Black			


# BACKGUARD PARTS



# BACKGUARD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	2		Panel, Backguard	4	98015526	Screw
	W10144828	White Left Hand		W10208451	White	5	W10145101	Support, Backguard
	W10144829	White Right Hand	3	W10493726	Screw	6	98009179	U-Nut


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10610297	Nut	14	W11509554	Valve, Saddle	25	98007410	Bracket, Regulator
2	98017582	Tubing, Gas (Left Front)	15	98005659	Screw	26	98007431	Fitting (3/8 in to 9/16 in)
3	W10122103	Bracket, Surface Burner	16	98017517	Screw	27	98013634	Screw
4	98017359	Tubing, Gas (Right Rear)	17	W11509621	Manifold Assembly	28	W10278150	Clip, Ignitor
5	W11281166	Java Tech Spark Module 4 POS	18	98009179	U-Nut	29	98008545	Screw (Black)
6	W10177394	Regulator	19	W10565875	Thermostat, Oven	30	98017171	Tubing (Manifold to Regulator)
7	W10110342	Tubing, Gas	20	98017348	Orifice, Natural (9.5K) (Left Front and Right Rear)	31	W10146346	Screw
8	W10212101	Spreader, Flame		98017587	Orifice, Natural (7.5K) (Right Front and Left Rear)	32	W10209656	Black
9	W10110343	Tubing, Gas (Right Front)	21	W11208965	Igniter, Hot Surface		W10209657	Natural (Left Rear)
10	98012138	Burner, Oven	22	98017516	Saddle, Bracket			FOLLOWING PARTS NOT ILLUSTRATED
11	W10493726	Screw	23	W10177392	Tubing (Regulator to Oven Valve)		W10207842	LP Spud Kit (For Use With LP)
12	W11562248	Harness, Switch	24	98013314	Locator, Burner			
13	W10205816	Valve, Oven						

# CHASSIS PARTS






# CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10116396	Box, Flue	18	98009179	U-Nut	35	W10180590	Back, Oven
2	98013690	Spring, Torsion (Flue Box)	19	W10121634	Baffle, Side	36	98010054	Support, Rear
3	W10168214	Box, Burner	20	98003944	Back, Main	37	W10193475	Power Cord
4		Panel, Side	21	W11522387	Seal, Oven	38	W10613666	Bracket, Anti-Tip
	W11501467	White	22	98006633	Screw	39	7101P485-60	Screw, Anti-Tip Kit
5	98005502	Clip, Oven Botton	23	W11522388	Seal, Door	40	98007193	Spacer
6	W10185442	Counterweight	24	98007126	Base, Foot	41	W11040327	Brick Support, Upper
7	W10165402	Cover, Main Rear	25	98006632	Screw	42	W10902689	Counterweight
8	W11513615	Frame, Front	26	W10554269	Socket - Oven Light	43	98006710	Counterweight
9	W10153610	Foot, Front	27	98007191	Shield, Heat (Lower)	44	W11036713	Support, Brick
10	W10058460	Foot, Leveling	28	W10788320	Bulb, Light	45	W10477747	Anti-Tip Kit
11	98004450	Bottom, Oven	29	98008545	Screw (Black)			FOLLOWING PARTS NOT ILLUSTRATED
12	98005642	Clip, Therm Bulb	30	W10555328	Seal, Broiler Door			
13	98003945	Baffle, Base	31	W10368736	Aluminum Foil	W10207891		Insulation, Top
14	98003830	Rail, Base	32	98006634	Screw	W10206735		Insulation, Wrap
15	98012912	Support, Oven Burner	33	98004448	Top, Oven			
16	98005642	Clip, Therm Bulb	34	98004452	Side, Oven (Right Hand)			
17	98006715	Shield, Channel		98004451	Side, Oven (Left Hand)			


# OVEN AND BROILER PARTS



# OVEN AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	98016942	Rack, Oven	9	98004700	Liner, Door	15	W11499074	Hanger, Brlr Door
2	98003480	Grill, Broiler	10	98003791	Support, Hinge	16	98008341	Cover, Guide
3	98016005	Pan, Broiler	11	W10137224	Insulation, Door	17	W10493726	Screw
4	98016570	Rack, Broiler	12		Panel, Door	18		Spring, Broiler
5	W10216805	Washer		98017156W	White		98009248	Right Hand
6	98004715	Guide, Rack	13		Handle, Broiler Door		98009249	Left Hand
7	98004219	Screw		98008486	White			
8	98008544	Screw (White)	14	98004053	Pin, Hinge			

# OVEN DOOR PARTS



# OVEN DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11516166	Liner, Door	10	8533842	Screw	20	98004981	Retainer, Insulation (Top)
2	W11513373	Retainer, Upper Insulation	11	98006727	Screw (White)	21	98004952	Clip, Glass (Left Hand)
3		Panel, Oven Door	12	98004650	Nut, Push		98004953	Clip, Glass (Right Hand)
	W11501931	White	13		Handle, Oven Door			
4	W11522388	Seal, Door		98004947	White			
5	98004564	Retainer (Right Hand)	14	98017873	Hinge, Oven Door (Yellow)	22	W10212525	Insulation, Door
	98004629	Retainer (Left Hand)	15	W10201296	Glass, Inner	23	W11502239	Insulation, Door
6	98004993	Screw	16	W10168624	Glass, Outer			
7	W10212696	Insulation, Door	17	W10212526	Insulation			
8	98008699	Screw	18	98004979	Bumper			
9	98006726	Screw (Black)	19	98012903	Retainer, Insulation (Bottom)			

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

## MISCELLANEOUS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	98012220	Kit, Door Pin