


AMANA®

GAS RANGE

MODELS:

AGR6603SFB8 (Black)
AGR6603SFW8 (White)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11450808	Owners Manual
	W11508881	Wiring Diagram
	W11427467	Quick Start Guide
2		Set, Burner Cap
	W11395131	Black (Set of 4)
3	W11352018	Spreader, Flame (Left Front, Right Front)
	W11352020	Spreader, Flame (Left Rear)
	W11352021	Spreader, Flame (Right Rear)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Cooktop
	W11331122	Black
	W11331123	White
5		Panel, Manifold
	8523855	Black
	8523854	White
6		Knob, Control
	W11510628	Black
	W11510627	White
7		Grate Kit (Set of Four)
	W10682667	Black
8	3196169	Screw
9	W10673618	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	8523249	Bracket, Manifold
11	W11379945	Bracket, Anti-Tip
12	7101P485-60	Screw, Anti-Tip Kit
		FOLLOWING PARTS NOT ILLUSTRATED
	W11457167	Harness, Main
	W11450461	Harness, Bake and Broil
	3196896	Clip, Wire
	3196520	Clip, Wire
	W10334923	Clip, Gas Wiring
	313438	Clip, Harness
	7111P017-60	Clamp, Wire


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W10920631	Module, Spark DSI	11		Control, Range
	W11130372	Black (Left)	5	W10516123	Bracket, Console Mounting		W11548220	Black
	W11130371	White (Left)					W11520694	White
	W11130379	Black (Right)	6	8523412	Bracket, Rear Cooktop	12	3196178	Screw
	W11130378	White (Right)	7	W10198745	Cover, Upper	13	W10516463	Bracket, DSI
2	W10110488	Module, Spark	8	W10192841	Shield, Heat	14	W10695491	Bracket, Control
3		Panel, Console	9	W10184370	Cover, Back	15	8053505	Shield, Heat
	W11157104	Black	10	3196169	Screw	16	W10797001	Bracket, Ignitor
	W11157106	White				17	3196165	Screw


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	10	3196265	Screw	24	W10827923	Electrode, Spring
2	W10949105	Bracket, Saddle Valve	11	3196385	Screw			(Left Front, Left Rear, Right Front, Right Rear)
3	W11459253	Orifice Holder Assembly (Left Front)	12	8054078	Burner, Broiler	25	W10182767	Tie, Manifold Wire
	W11459254	Orifice Holder Assembly (Left Rear)	13	W10184491	Spreader, Flame (Oven)			FOLLOWING PARTS NOT ILLUSTRATED
	W11459255	Orifice Holder Assembly (Right Front)	14	9758078	Burner, Bake	W10566537		LP Bake and Broil Kit
	W11459256	Orifice Holder Assembly (Right Rear)	15	W11370883	Regulator	W11489400		LP Conversion Kit
4	W10215439	Tubing (Manifold to Regulator)	16	W10333842	Electrode, Broil	W10400495		Orifice, LP Bake
5	W11537750	Harness, Switch	17	W10420040	Tube, Broiler Supply	W10465080		Orifice, LP Broil
6	W10224921	Bracket, Aegis	18	W11435700	Fitting, Broiler			
7	W11510001	Manifold Assembly	19	3400016	Screw			
8	W11509685	Valve, Gas (Left Front, Right Front)	20	W11485872	Orifice (15K) (Left Front, Right Front)			
	W11509686	Valve, Gas (Left Rear)		W11485873	Orifice (9.5K) (Left Rear)			
	W11509687	Valve, Gas (Right Rear)		W11485871	Orifice (5K) (Right Rear)			
9	W10362924	Screw	21	W10137062	Spreader, Flame (Broiler)			
			22	W11450459	Electrode, Bake			
			23	W11428831	Electrode (Left Front, Left Rear)			
				W11428858	Electrode (Right Front, Right Rear)			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	14	W10390008	Base Rail Assembly (Left)	24	W10379120	Screw
2	8272747	Shield, Flue				25	W11634772	Light Assembly
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	26	W10571723	Bulb, Halogen 40 Watts
4		Panel, Side	15	W10362924	Screw	27	3196560	Screw
	W10162245	Black	16	W10031780	Screw	28	W10674705	Glide, Drawer Front
	W10575396	White	17	W10107820	Rear Door Latch Assembly	29	W11511828	Switch, Door
5	3196178	Screw	18	W11491751	Seal, Door	30	9761013	Front Door Latch Assembly
6	3196169	Screw	19	W10435470	Brace, Main Back	31	9757239	Rod, Door Switch
7	W10341186	Front Foot Assembly	20	W11379353	Retainer, Insulation (Left)	32	W10078370	Rod, Push Latch
8	W10058460	Foot, Leveling						FOLLOWING PARTS NOT ILLUSTRATED
9	3195097	Bottom, Oven		W11379943	Retainer, Insulation (Right)		8524099	Insulation, Wrap
10	W10586204	Sensor	21	W10137382	Clip, Panel		W10180437	Insulation, Back
11	8053967	Baffle, Burner Oven	22	W10624590	Cord, Power			
12	8053969	Shield, Heat	23	W10289077	Receiver, Hinge			
13	8053968	Shield, Lower						


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top Vent	9	W11380222	Retainer, Insulation	15	W11379944	Strap, Door
	W10310922	Black	10	W10299227	Hinge, Door (Passive)	16	W10031780	Screw
	W10310920	White		W10299226	Hinge, Active	17		Trim, Bottom
2	W10168559	Screw					W11444043	Black
3		Handle, Door	11		Glass, Outer Door		W11444042	White
	W10323589	Black		W10886896	Black	18	W10316950	Frame, Glass
	W10323588	White		W10851723	White			
4	9761344	Liner, Door	12		Trim, Door Side			
5	W10031790	Screw		W10746436	Black (Left)			
6	9758162	Glass, Inner		8523172	White (Left)			
7		Badge		W10746435	Black (Right)			
	W10846751	Black		8523166	White (Right)			
	W10849465	White	13	W10327235	Screw			
8	W10278991	Insulation, Door Strip	14	W10200660	Screw			

DRAWER AND BROILER PARTS



DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11173792	Rack, Oven	5		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11123976	Black
3	W10462911	Bracket, Mounting		W11123977	White
4		Rivet, Push	6	W10674708	Glide, Drawer Rear
	3196813	Black	7	3196169	Screw
	3196814	White			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	285006	Black
	206922	Primer (White)
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORIES NOT INCLUDED OR ILLUSTRATED
	30-48KITRC	Gas Range Connector Kit
	4396923	Broiler Pan and Grid
	4396096RB	Griddle