

KitchenAid®


30" ELECTRIC DOWNDRAFT COOKTOP

MODELS:

KCED600GBL01 (Black)

KCED600GSS01 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	8273994	Element (1200W) (Right Front)	14	7101P427-60	Screw
	W10848428	Instructions, Installation		W10342780	Element (1300W) (Left Rear)	15	8008P068-60	Grommet, Wire (Black) (Small Hole)
	W10848424	Instructions, User	6	7101P426-60	Screw	16	3183956	Seal, Switch Cover
	W10917804	Sheet, Tech	7	W10225448	Spring, Element	17		Bezel, Knob
	W11026765	Diagram, Wiring	8	W10324729	Grommet, Wire (Gray) (Large Hole)		W10593536	Stainless
2		Top			Knob, Control	18	W10912406	Shield, Heat FOLLOWING PARTS NOT ILLUSTRATED
	W10796748	Black	9	W10884728	Stainless		W11190475	Harness, Cooktop
	W10796749	Stainless (Stainless Model Includes Trim)	10	W10815302	Bracket, Switch		W11190478	Harness, Blower
3	7101P309-60	Screw	11	W10437094	Switch, Infinite (Left Front & Left Rear)		W11190480	Harness, Jumper
4	W10251108	Element (3200W) (Left Front)		W10578768	Switch, Infinite (Right Front)		W10909126	Kit, Plenum Screw 3192439 Seal, Limiter 8286642 Tape, Foam 7101P460-60 Screw, Grounding
	W10275048	Element (3000/1400W) (Right Rear)		W10437092	Switch, Infinite (Right Rear)			
			12	W10866567	Switch, Blower			
			13		Grille, Air Black			
				W10205094				


BLOWER UNIT PARTS



BLOWER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10872755	Assembly, Top Plenum	3	7103P162-60	Nut, Lock	6	W10837738	Assembly, Lower Plenum
2	W10877782	Assembly, Downdraft Blower	4	7109P086-60	Washer	7	W10837737	Panel, Lower Plenum Access
			5	W10815866	Filter, Grease			

BURNER BOX PARTS



BURNER BOX PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10815392	Rail, Straight
2	W10235990	Tray, Spill

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Box, Burner (Not Serviced)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10258697	Cover, Blower Motor Harness
5	7101P426-60	Screw

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	W10355016	Cleaner, Stainless Steel