

KitchenAid®


36" ELECTRIC DOWNDRAFT COOKTOP

MODELS:

KCED606GBL01 (Black)

KCED606GSS01 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W10225448	Spring, Element	16	3183956	Seal, Switch Cover
	W10848428	Instructions, Installation	8	W10324729	Grommet, Wire (Gray) (Large Hole)			FOLLOWING PARTS NOT ILLUSTRATED
	W10848424	Instructions, User	9		Knob, Control	W11134610		Harness, Main
	W10917816	Sheet, Tech		W10884728	Stainless	W11190478		Harness, Blower
	W11026766	Diagram, Wiring	10	W10834481	Bracket, Switch	7101P460-60		Screw
2		Top	11	W10437094	Switch, Infinite (Left Front & Center Front)	W11190480		Harness, Jumper
	W10795401	Black				W10909126		Kit, Plenum Screw
	W10795402	Stainless (Stainless Model Includes Trim)		W10843843	Switch, Infinite (Left Rear)	3192439		Seal, Limiter
3	7101P309-60	Screw		W10578768	Switch, Infinite (Center Rear)	8286642		Tape, Foam
4	W10342780	Element (1300W) (Left Front)		W10437092	Switch, Infinite (Right Rear)			
	8273993	Element (1800W) (Left Rear)	12	W10866567	Switch, Blower			
	W10251108	Element (3200W) (Center Front)	13		Grille, Air			
	8273994	Element (1200W) (Center Rear)		W10205094	Black			
	W10711900	Element (3000W) (Right Rear)	14	7101P427-60	Screw			
5		Bezel, Knob	15	8008P068-60	Grommet, Wire (Black) (Small Hole)			
	W10593536	Stainless						
6	7101P426-60	Screw						


BLOWER UNIT PARTS



BLOWER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10872755	Assembly, Top Plenum	3	7103P162-60	Nut, Lock	6	W10837738	Assembly, Lower Plenum
2	W10877782	Assembly, Downdraft Blower	4	7109P086-60	Washer	7	W10837737	Panel, Lower Plenum Access
			5	W10815866	Filter, Grease			

BURNER BOX PARTS



BURNER BOX PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10815392	Rail, Straight	4	W10258697	Cover, Blower Motor Harness	6	W10815650	Rail, Right
2	W10235990	Tray, Spill				7	W10872311	Rail, Element Support
3		Box, Burner (Not Serviced)	5	7101P426-60	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
W10355016		Cleaner, Stainless Steel
W10355051		Cleaner, Cooktop
WA906B		Scraper, Cooktop