


KitchenAid®

COOKTOP

MODELS:

KCGD500GSS05 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Knob, Fan	15		Bezel
	W11468900	Owner's Manual		W10884724	Stainless		W10884725	Stainless
	W11466944	Quick Start Guide	9		Knob, Control	16	W11508237	Seal, Downdraft Pad
	W11565447	Sheet, Tech		W11514464	Stainless	17	W10868745	Bracket, Switch Mount
2		Top, Main	10		Grate Kit (Includes 3 Grates)	18	7101P309-60	Screw
	W10842288	Stainless		W11241661	Black	19	W10827923	Electrode, Spring
3	W10826752	Holder, Orifice (17K)	11	W10907865	Orifice			FOLLOWING PARTS NOT ILLUSTRATED
		(Left Front)			(Left Front)		W11465116	Harness, Main
	W10826751	Holder, Orifice (5k)		W10849719	Orifice (5K)		W11190478	Harness, Blower
		(Left Rear)			(Left Rear)		W11465762	Harness, Jumper
	W10826754	Holder, Orifice (10K)		W10907868	Orifice		7101P460-60	Screw, Grounding
		(Right Front)			(Right Front)		W10831977	Cord, Power
	W10826753	Holder, Orifice (15K)		W10907866	Orifice		W10132200	Relief, Strain
		(Right Rear)	12	W10866564	Switch, Blower		W10183556	Clip, Wire
4	W10910373	Kit, Burner Cap	13	4455917	Bracket, Cooktop Mounting		W10909126	Kit, Plenum Screw
5	W10732971	Flame Spreader	14	W10862325	Electrode		W11022461	Kit, LP Orifice
		(Left Front & Right Rear)			(Left Front)			
	W10732968	Flame Spreader		W10862326	Electrode			
		(Left Rear)			(Left Rear)			
	W10732969	Flame Spreader		W10862323	Electrode			
		(Right Front)			(Right Front)			
6	7101P426-60	Screw		W10862324	Electrode			
7	3400093	Screw			(Right Rear)			


BLOWER UNIT PARTS



BLOWER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10836514	Assembly, Top Plenum	4	W10837737	Panel, Lower Plenum Access	8	W10235990	Tray, Spill
2	W10877782	Assembly, Downdraft Blower	5	W10815866	Filter, Grease	9	W11249635	Screw
3	W10837738	Assembly, Lower Plenum	6	7103P162-60	Nut, Lock			
			7	7109P086-60	Washer			

BURNER BOX PARTS



BURNER BOX PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11512355	Manifold Assembly	10	W11511840	Valve (Left Front & Right Rear)	15	W11577790	Screw
2		Box, Burner (Not Serviced)				16	W10826747	Assembly, Tube (Left Front)
3	W10258697	Cover, Blower Motor Harness		W11511841	Valve (Left Rear)	17	W10826748	Assembly, Tube (Left Rear)
4	7101P426-60	Screw		W11511839	Valve (Right Front)	18	W10826749	Assembly, Tube (Right Front)
5	W10811211	Bracket, Hat	11	W10949105	Bracket, Saddle Valve	19	W10826750	Assembly, Tube (Right Rear)
6	W10894861	Cover, Spark	12	W10449143	Regulator, Pressure	20	W11508234	Seal, Downdraft Shaft
7	W10475147	Module, Spark	13	W11507167	Seal, Switch Shaft			
8	7208P024-60	Seal, Manifold Pipe Inlet	14	W11537635	Harness, Switch			
9	3400804	Screw, Bracket						

OPTIONAL PARTS NOT INCLUDED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORY PARTS
	W11042467	Spray, Stainless Steel Cleaning
	W10620783	Kit, Ductless Downdraft Vent
	W10177003	Filter (Ductless)