


KitchenAid®

GAS COOKTOP

MODELS:

KCGS356ESS06 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286814	Head, Burner (Left Front & Left Rear)	12	W11439331	Wiring, Electrode (Left Front and Right Front)
	W11468901	Owner's Manual		8286815	Head, Burner (Right Front)		W11439332	Wiring, Electrode (Left Rear and Right Rear)
	W11466943	Quick Start Guide		8286813	Head, Burner (Right Rear)			
2	W10597068	Cooktop	9	W10625915	Black	13	W10611434	Head, Burner FOLLOWING PARTS NOT ILLUSTRATED
3		Burner Cap Kit	10	W10763330	Electrode, Stack (Center)		W11665047	Harness, Switch
	W10597132	Black	11	W10652710	Orifice (Left Front & Left Rear)		W10878749	Harness, Spark Module
4		Grate Kit (Includes 3 Grates)		W10409144	Orifice (Right Front)		3400015	Screw, Grounding
	W11241669	Black		W10652711	Orifice (Right Rear)		3801F935-51	Bracket, Tie Down
5	8286863	Spring, Electrode		W10409146	Orifice (19K) (Center, Main)		7101P062-60	Screw (Used For Tie Down Bracket)
6		Knobs, Cooktop		W10652706	Orifice (Center, Simmer)		W10392003	Cord, Power
	W10545849	Stainless					W10132200	Relief, Strain
7	W10597166	Holder, Orifice (9.1K) (Left Front & Left Rear)					9760045	Seal, Foam
	W10594405	Holder, Orifice (12K) (Right Front)					8270P188-60	Tape, Foam
	W10594399	Holder, Orifice (5K) (Right Rear)					313438	Clip, Harness
	W10639869	Holder, Orifice (19K) (Center)					W10676661	Kit, LP Conversion

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	6	W10614951	Panel, Front	15	W10566307	Tubing, Gas Burner
2	W11673572	Pipe Manifold Assembly	7	W10449143	Regulator, Pressure			(Right Rear)
3	W11672772	Valve, Single (Left Front)	8	W10594429	Bracket, Orifice Holder	16	W10566296	Tubing, Gas Burner
	W11672768	Valve, Single (Left Rear)	9	W11350452	Spark Module			(Center, Main)
	W11672770	Valve, Single (Right Front)	10	W11678089	Box, Burner	17	W10566297	Tubing, Gas Burner (Simmer)
	W11672771	Valve, Single (Right Rear)	11	W11507167	Seal, Switch Shaft			(Center, Simmer)
	W11672773	Valve, Dual (Center)	12	W10566305	Tubing, Gas Burner (Left Front)	18	W10594430	Bracket, Orifice Holder
4	8287055	Bracket, Single Valve	13	W10566306	Tubing, Gas Burner (Left Rear)	19	3196537	Screw
5	8287056	Bracket, Dual Valve	14	W10566308	Tubing, Gas Burner (Right Front)	20	7101P426-60	Screw
						21	W10443110	Screw
						22	8286921	Screw, Burner Rail (M4)