


KitchenAid®

GAS COOKTOP

MODELS:

KCGS550ESS06 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286815	Head, Burner (Left Front and Right Front)	15	W10657994	Electrode, Burner
	W10672375	Instructions, Undercounter Install				16	W10416057	O-Ring
	W11468901	Owner's Manual		8286813	Head, Burner (Left Rear)	17	8286863	Spring, Electrode
	W11466943	Quick Start Guide		8286814	Head, Burner (Right Rear)	18		Burner Cap, Outer
2		Cooktop					W10617405	Black
	W10722084	Stainless						INSULATION PARTS NOT ILLUSTRATED
3		Kit, Burner Cap	9		Bezel		W10617403	Insulation, Cooktop
	W10617345	Black		W10593536	Stainless			FOLLOWING PARTS NOT ILLUSTRATED
4		Grate Kit (Includes 3 Grates)	10	W10583862	Grate, Center			
	W11108276	Black	11	W10674732	Orifice (10K) (Left Front and Right Front)		W11632147	Harness, Switch
5		Kit, Burner Cap		W10151353	Orifice (Left Rear)		W10878749	Harness, Spark Module
	W10635600	Black (Includes Melt Cap)		W10674728	Orifice (Right Rear)		3801F935-51	Bracket, Tie Down
6		Knobs, Cooktop					7101P062-60	Screw (Used For Tie Down Bracket)
	W10545849	Stainless	12	W11439331	Wiring, Electrode (Left Front and Right Front)		3400015	Screw, Grounding
7	W10674920	Holder, Orifice (10K) (Left Front and Right Front)		W11439332	Wiring, Electrode (Left Rear and Right Rear)		W10392003	Cord, Power
	W10674918	Holder, Orifice (6K) (Left Rear)					W10132200	Relief, Strain
	W10674919	Holder, Orifice (7K) (Right Rear)	13	W10808715	Spreader, Burner		W10676662	Kit, LP Conversion
			14	W10625853	Assembly, Burner Base (17K)			

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	8	W10594429	Bracket, Orifice Holder	16	W10545800	Tubing, Gas Burner (Center, Simmer)
2	W11673573	Pipe Manifold Assembly	9	W11350452	Spark Module	17	W10443110	Screw
3	W11629615	Valve, Single (Left Front and Right Front)	10	W10710916	Box, Burner	18	W11507167	Seal, Switch Shaft
	W11629616	Valve, Single (Left Rear)	11	W10545802	Bracket, Dual Burner	19	3196537	Screw
	W11629617	Valve, Single (Right Rear)	12	W10545796	Tubing, Gas Burner (Left Front and Right Front)	20	7101P426-60	Screw
	W11629618	Valve, Dual (Center)	13	W10545797	Tubing, Gas Burner (Left Rear)	21	8286921	Screw, Burner Rail (M4)
4	8287055	Bracket, Single Valve	14	W10545798	Tubing, Gas Burner (Right Rear)			ACCESSORIES NOT INCLUDED OR ILLUSTRATED
5	8287056	Bracket, Dual Valve	15	W10545801	Tubing, Gas Burner (Center, Main)		W10662080	Griddle
6	W10705474	Panel, Front						
7	W10449143	Regulator, Pressure						