

**KitchenAid®**

**ELECTRIC WALL OVEN**


**MODELS:**

KOED530PWH00 (White)

KOED530PSS00 (Stainless)

KOED530PBS00 (Black Stainless)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W11339492	Screw (Black)	16	W11244445	Cover, 30 IN Chassis Top Front
	W11656312	Owner's Manual	5	W11397930	Blower			
	W11618058	Quick Start Guide	6	W11162063	Gasket, Rubber	17	W11223325	Cover, 30 IN Chassis Top Back
	W11479717	Wiring Diagram	7	W10728475	Gasket, Rubber			
	W11340883	Tech Manual	8	7101P426-60	Screw			FOLLOWING PARTS NOT ILLUSTRATED
2		Assembly, Control Panel (Includes Overlay)	9	7101P434-60	Screw			
	W11640533	White	10	W10655463	Bracket, Blower (Left)	W11245674		Harness, Main
	W11640534	Stainless		W10655462	Bracket, Blower (Right)	W11256625		Harness, Signal
	W11640549	Black Stainless	11	4451758	Block, Foam	W11264646		Harness, Door Latch
3	W11249218	Appliance Manager, Copernicus (Upper)	12		Skin, Control Panel	W10562910		Harness, EOL
	W11249217	Appliance Manager, Copernicus (Without Power Supply) (Lower)		W10588746	White	4450800		Screw, Grounding
				W10588740	Stainless	313438		Clip, Harness
				W10776407	Black Stainless	W11132988		Strap, Lead Ground
			13	W11179509	Tray, Electronic	4448664		Clamp, Conduit
			14	W11166802	Divider, Chassis Back	W10655464		Bracket, Harness
			15	W10351295	Bumper	W11394923		Bag, Hardware


# OVEN PARTS



# OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11165250	Duct, Chassis Back (Upper)	20		Assembly, Bottom Vent	33	W11256423	Base, Vent Exhaust
2	W11085298	Tube, Vent		W11467336	Black (Used in White and Black Stainless Models)	34	W11186652	Bracket, U-Shape
3	W11256432	Deflector, Lower Back Exhaust				35	W11235482	Vent, Center 30"
4	W11558603	Spacer, Base		W11467754	Stainless	36	W11334857	Vent, Top 30 IN
5	W11655005	Latch, Motorized	21	W11244446	Duct, Bottom Chassis	37	W11249635	Screw
6	W11168071	Top, Chassis	22		Trim, Bottom Vent	38	W11342780	Bracket, Top Front
7	W11205574	Assembly, Oven Light				39	W11167419	Cover, Suction (Left)
8	W11245118	Foot, Base		W11624689	Black		W11186675	Cover, Suction (Right)
9	W10904163	Deflector, Blower	23	W11135135	Support, Air Channel	40	W11256420	Base, Top Back Exhaust
10	W11344645	Hat Bracket, Vent	24	W11390667	Spacer, Chassis Bottom Duct	41	W11256421	Cover, Top Back Exhaust
11	W11608108	Gasket	25	W11245114	Foot, Chassis (Left)	42	W11256430	Base, Lower Back Exhaust
12	W11256424	Cover, Vent Exhaust		W11245116	Foot, Chassis (Right)	43	W11256431	Cover, Lower Back Exhaust
13	W11165274	Side, Chassis	26	8285593	Cover, Connector	44	W11533682	Cover, WIFI
14	W11223327	Back, Chassis	27	7101P426-60	Screw	45	W11211345	Foam, U-Bracket
15		Liner, Oven (Not Serviceable)	28	W10472386	Lens, Light			FOLLOWING PARTS NOT ILLUSTRATED
16	W11346074	Probe, Sensor	29	W11235460	Cover, Side Trim (Left)			
17	W11166315	Bumper and Screw		W11235461	Cover, Side Trim (Right)		W11188284	Insulation, Wrap
18	4449751	Thermostat (TOD)					W11234758	Insulation, Cavity
19	W11135103	Base, Chassis	30	W11404000	Screw			
			31	W10472384	Bulb, Light			
			32	W11134657	Duct, Lower Chassis Back			


# UPPER OVEN DOOR PARTS



# UPPER OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302587	Liner Assembly	9	W10254050	Screw	14	W10319024	Washer, Door
2	7101P375-60	Screw	10	W11633413	Hinge, Door (Left)	15		Handle Assembly
3	W11290045	Screw		W11633414	Hinge, Door (Right)		W11241572	Stainless
4	W10618107	Glass, Inner	11	3196183	Screw	16	W10551026	Medallion, Handle
5	W11302730	Spacer, Air Divider	12	W11317731	Screw (Black)	17	W10656499	Screw
6	W11174095	Retainer, Air Divider Glass	13		Door Assembly			
7	7101P426-60	Screw		W11264076	White			
8	W11100732	Receiver, Hinge		W11295957	Stainless			
				W11295959	Black Stainless			

# LOWER OVEN DOOR PARTS






# LOWER OVEN DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302587	Liner Assembly	9	W10254050	Screw	15		Handle Assembly
2	7101P375-60	Screw	10	W11633413	Hinge, Door (Left)		W11241572	Stainless
3	W11290045	Screw		W11633414	Hinge, Door (Right)	16	W10551026	Medallion, Handle
4	W10618107	Glass, Inner	11	3196183	Screw	17	W10656499	Screw
5	W11302730	Spacer, Air Divider	12	W11317731	Screw (Black)	18	W10518672	Badge
6	W11174095	Retainer, Air Divider Glass	13		Door Assembly			
7	7101P426-60	Screw		W11264076	White			
8	W11239070	Receiver, Hinge (Left)		W11295957	Stainless			
	W11239072	Receiver, Hinge (Right)		W11295959	Black Stainless			
			14	W10319024	Washer, Door			

# INTERNAL OVEN PARTS



# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	10	W11425715	Blade, Fan	18	W10554531	Rack, Sliding
2	W10554526	Rack, Oven	11	W10546519	Element, Convection	19	9755542	Probe, Temperature
3	W10318198	Tray, Hidden Bake	12	W10819989	Baffle, Bow Tie	20	W10720084	Screw
4	7101P434-60	Screw		W10918895	Baffle, Bow Tie	21	W11398057	Cover, Convect Plate
5	7101P426-60	Screw			(For Black Stainless Models)	22	W11251715	Plate, Convect Motor
6	W10282957	Crossbar, Hidden Bake Tray	13	W11235537	Reflector, Broil	23	W11251716	Insulation, Convect Motor
7	W11292248	Element, Bake	14	W10588737	Shield, Broil Front	24	W11661815	Basket, Airfry
8	W11398058	Convect Motor Assembly	15	W11252826	Jack, Meat Probe			
9	W11433702	Nut, Acorn (LH)	16	W11033111	Nut, Locking			
			17	W10906658	Screw			

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	285006	Black
	350938	Gray Primer
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
		Assembly, Bottom Vent
	W11369884	Black
	W11369889	Stainless Trim, Tall Vent
	W11570325	Black
	W11570323	Stainless Vent, Deflector
	W11594553	Black
	W11551866	Stainless