

KitchenAid®


ELECTRIC WALL OVEN

MODELS:

KOES527PSS00 (Stainless)

KOES527PBS00 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W11533682	Cover, WIFI	16	W11244459	Cover, Top Back 27 IN Chassis
	W11656312	Owner's Manual	8	7101P426-60	Screw			
	W11618058	Quick Start Guide	9	W10728475	Gasket, Rubber			FOLLOWING PARTS NOT ILLUSTRATED
	W11382212	Wiring Diagram	10	W10655463	Bracket, Blower (Left)			
	W11340883	Tech Manual		W10655462	Bracket, Blower (Right)		W11245665	Harness, Main
2		Assembly, Control Panel (Includes Overlay)	11	4451758	Block, Foam		W11256622	Harness, Signal
	W11640545	Stainless	12		Skin, Control Panel		W11264646	Harness, Door Latch
	W11640555	Black Stainless		W10588741	Stainless		W10562910	Harness, EOL
3	W11249218	Appliance Manager, Copernicus		W10861075	Black Stainless		4450800	Screw, Grounding
4	W11339492	Screw (Black)	13	W11179509	Tray, Electronic		W10487999	Clip, Harness
5	W11397930	Blower	14	W11166802	Divider, Chassis Back		W11132988	Strap, Lead Ground
6	W11162062	Gasket, Rubber (652 MM)	15	W11244469	Cover, Top Front 27 IN Chassis		4448664	Clamp, Conduit
							W10655464	Bracket, Harness
							W11547720	Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11165250	Duct, Chassis Back	16	W11346074	Probe, Sensor	28	W10472386	Lens, Light
2	W11085298	Tube, Vent	17	W11166315	Bumper and Screw	29		Cover, Side Trim
3	W11100732	Receiver, Hinge	18	4449751	Thermostat (TOD)		W11235463	Black (Left)
4	W11558603	Spacer, Base	19	W11244454	Base, Chassis		W11235462	Black (Right)
5	W11655005	Latch, Motorized	20		Assembly, Bottom Vent	30	W11404000	Screw
6	W11244456	Top, Chassis		W11467824	Stainless	31	W10472384	Bulb, Light
7	W11205574	Assembly, Oven Light		W11467807	Black	32	W11256423	Base, Vent Exhaust
8	W11245118	Foot, Base	21	W11244446	Duct, Bottom Chassis	33	W11249635	Screw
9	W10904163	Deflector, Blower	22		Trim, Bottom Vent	34	W11167419	Cover, Suction (Left)
10	W10254050	Screw		W11624688	Black		W11186675	Cover, Suction (Right)
11	W11608109	Gasket, Cavity	23	W11135135	Support, Air Channel			FOLLOWING PARTS NOT ILLUSTRATED
12	W11256424	Cover, Vent Exhaust	24	W11390667	Spacer, Chassis Bottom Duct		W11244474	Insulation, Wrap
13	W11165274	Side, Chassis	25	W11334858	Vent, Top 27 in		W11244475	Insulation, Back
14		Back, Chassis (Not Serviced)	26	8285593	Cover, Connector			
15		Liner, Oven (Not Serviceable)	27	7101P426-60	Screw			


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302593	Liner Assembly	8	W11633416	Hinge, Door (Left)	13	W10518672	Badge
2	7101P375-60	Screw		W11633417	Hinge, Door (Right)	14		Handle Assembly
3	W11290045	Screw	9	3196183	Screw		W11241574	Stainless
4	W10618123	Glass, Inner	10	W11317731	Screw (Black)	15	W10551026	Medallion, Handle
5	W11302731	Spacer, Air Divider	11		Door Assembly	16	W10656499	Screw
6	W11204277	Retainer, Air Divider Glass		W11295967	Stainless			
				W11295968	Black Stainless			
7	7101P426-60	Screw	12	W10319024	Washer, Door			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	10	W11433702	Nut, Acorn (LH)	18	W10554532	Rack, Sliding
2	W10554529	Rack, Oven	11	W10546519	Element, Convection	19	9755542	Probe, Temperature
3	W10318198	Tray, Hidden Bake	12	W10819989	Baffle, Bow Tie	20	W10906658	Screw
4	7101P434-60	Screw		W10918895	Baffle, Bow Tie	21	W11251715	Plate, Convect Motor
5	7101P426-60	Screw			(Black Stainless Models Only)	22	W11251716	Insulation, Convect Motor
6	W10282957	Crossbar, Hidden Bake Tray	13	W11235537	Reflector, Broil	23	W11398057	Cover, Convect Plate
7	W11292248	Element, Bake	14	W10588737	Shield, Broil Front	24	W11661815	Basket, Airfry
8	W11398058	Convect Motor Assembly	15	W11252826	Jack, Meat Probe			
9	W11425715	Blade, Fan	16	W11033111	Nut, Locking			
			17	W10720084	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	285006	Black
	350938	Gray Primer
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORY PARTS
		Trim, Tall Vent
	W11570324	Stainless
	W11570326	Black
		Trim, Bottom Vent
	W11369891	Stainless
	W11369893	Black
		Vent, Deflector
	W11594554	Black
	W11551865	Stainless