

KitchenAid®

ELECTRIC WALL OVEN


MODELS:

KOES530PWH00 (White)

KOES530PSS00 (Stainless)

KOES530PBS00 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W10728475	Gasket, Rubber	16	W11223325	Cover, 30 IN Chassis Top Back
	W11656312	Owner's Manual	8	7101P426-60	Screw			
	W11618058	Quick Start Guide	9	7101P434-60	Screw			FOLLOWING PARTS NOT ILLUSTRATED
	W11340883	Tech Manual	10	W10655463	Bracket, Blower (Left)			
	W11382212	Wiring Diagram		W10655462	Bracket, Blower (Right)		W11245665	Harness, Main
2		Assembly, Control Panel (Includes Overlay)	11	4451758	Block, Foam		W11256622	Harness, Signal
	W11640535	White	12		Skin, Control Panel		W11264646	Harness, Door Latch
	W11640536	Stainless		W10588746	White		W10562910	Harness, EOL
	W11640550	Black Stainless		W10588740	Stainless		4450800	Screw, Grounding
3	W11249218	Appliance Manager, Copernicus		W10776407	Black Stainless		W10487999	Clip, Harness
4	W11339492	Screw (Black)	13	W11179509	Tray, Electronic		W11132988	Strap, Lead Ground
5	W11397930	Blower	14	W11166802	Divider, Chassis Back		4448664	Clamp, Conduit
6	W11162063	Gasket, Rubber	15	W11244445	Cover, 30 IN Chassis Top Front		W10655464	Bracket, Harness
							W11547720	Bag, Hardware


OVEN PARTS



OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11165250	Duct, Chassis Back	17	W11166315	Bumper and Screw	27	7101P426-60	Screw
2	W11085298	Tube, Vent	18	4449751	Thermostat (TOD)	28	W10472386	Lens, Light
3	W11100732	Receiver, Hinge	19	W11135103	Base, Chassis	29		Cover, Side Trim
4	W11558603	Spacer, Base	20		Assembly, Bottom Vent		W11235463	Black (Left)
5	W11655005	Latch, Motorized		W11467336	Black		W11235462	Black (Right)
6	W11168071	Top, Chassis			(Used in White and Black Stainless Models)	30	W11404000	Screw
7	W11205574	Assembly, Oven Light				31	W10472384	Bulb, Light
8	W11245118	Foot, Base		W11467754	Stainless	32	W11256423	Base, Vent Exhaust
9	W10904163	Deflector, Blower	21	W11244446	Duct, Bottom Chassis	33	W11249635	Screw
10	W10254050	Screw	22		Trim, Bottom Vent	34	W11167419	Cover, Suction (Left)
11	W11608108	Gasket		W11624689	Black		W11186675	Cover, Suction (Right)
12	W11256424	Cover, Vent Exhaust	23	W11135135	Support, Air Channel	35	W11533682	Cover, WIFI
13	W11165274	Side, Chassis		W11135135	Support, Air Channel			FOLLOWING PARTS NOT ILLUSTRATED
14	W11223327	Back, Chassis	24	W11390667	Spacer, Chassis Bottom Duct		W11188284	Insulation, Wrap
15		Liner, Oven (Not Serviceable)	25	W11334857	Vent, Top 30 IN		W11234758	Insulation, Cavity
16	W11346074	Probe, Sensor	26	8285593	Cover, Connector			


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11302587	Liner Assembly	8	W11633413	Hinge, Door (Left)	12	W10319024	Washer, Door
2	7101P375-60	Screw		W11633414	Hinge, Door (Right)	13	W10518672	Badge
3	W11290045	Screw	9	3196183	Screw	14		Handle Assembly
4	W10618107	Glass, Inner	10	W11317731	Screw (Black)		W11241572	Stainless
5	W11302730	Spacer, Air Divider	11		Door Assembly	15	W10551026	Medallion, Handle
6	W11174095	Retainer, Air Divider Glass		W11264076	White	16	W10656499	Screw
7	7101P426-60	Screw		W11295957	Stainless			
				W11295959	Black Stainless			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11238159	Element, Broil	10	W11433702	Nut, Acorn (LH)	18	W10554531	Rack, Sliding
2	W10554526	Rack, Oven	11	W10546519	Element, Convection	19	9755542	Probe, Temperature
3	W10318198	Tray, Hidden Bake	12	W10819989	Baffle, Bow Tie	20	W10720084	Screw
4	7101P434-60	Screw		W10918895	Baffle, Bow Tie	21	W11398057	Cover, Convect Plate
5	7101P426-60	Screw			(For Black Stainless Models)	22	W11251715	Plate, Convect Motor
6	W10282957	Crossbar, Hidden Bake Tray	13	W11235537	Reflector, Broil	23	W11251716	Insulation, Convect Motor
7	W11292248	Element, Bake	14	W10588737	Shield, Broil Front	24	W11661815	Basket, Airfry
8	W11398058	Convect Motor Assembly	15	W11252826	Jack, Meat Probe			
9	W11425715	Blade, Fan	16	W11033111	Nut, Locking			
			17	W10906658	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	72032	Black
		PAINT, SPRAY
	285006	Black
	350938	Gray Primer
		ADHESIVE
	482338	Sealer, Silastic
		ACCESSORIES
		Trim, Tall Vent
	W11570325	Black
	W11570323	Stainless
		Assembly, Bottom Vent
	W11369889	Stainless
	W11369884	Black
		Vent, Deflector
	W11594553	Black
	W11551866	Stainless