


KitchenAid®

REFRIGERATOR

MODELS:

KRQC506MPS00 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3		Bottom Hinge Assembly	9	W11306512	Mullion, Pivot Block
	W11446054	Tech Sheet (Located in Machine Compartment)		W11024900	Left Hand	10	W11470190	Cover, Screw
	W11209377	Use & Care Guide		W11022521	Right Hand	11	W11029002	Lid, Main PCB
	W11438985	Energy Guide	4		Roller (Not Serviced)	12	W11442897	Assembly, Main Control Board
2		Middle Hinge Assembly	5	W11029028	Cover, Top Hinge	13		Top Hinge
	W11022529	Left Hand	6	W11115055	Switch, Reed		W11024899	Left Hand
	W11022519	Right Hand	7	W11040893	Sensor, Humidity / Temperature		W11028889	Right Hand
			8	W10916542	Harness, Top Hinge	14	W11039081	Cover, Machine


LINER PARTS



LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Cabinet Assembly (Not Serviceable)	9	W11097849	Evaporator, Freezer (Also Order the Following Lokring Parts)	14	W11032663	EPS, Evaporator Cover
2	W11048980	Assembly, Lamp				15	W11654046	Rear Evaporator Cover, FC
3	W11032353	Cover, Light				16	W11101594	Assembly, Fan Motor
4	W11654042	Light Trim	W11481106	3/1.8-NR-MS-00 (Suction Line to Evaporator)		17	W11135456	Thermistor, Refrigerator
5	W11659197	Air Tower Cover-RC				18	W11135458	Thermistor, Freezer
6	W11176100	Cover, Fresh Lighting	W10896689	5/4-NR-MS-00 (Capillary Tube to Evaporator)		19	W11135455	Thermistor, Defrost
7	W11369813	Cover, Damper				20	W11135457	Thermistor, CC
8	W11050016	Air Damper	10		EPS Block	21	W11654047	Single Piont LED, Freezer Compartment
				W11396540	Left Hand			
				W11028106	Right Hand	22	W11654048	Air Return Duct Grille
			11	W11318188	Heater, Defrost			
			12	W11028971	Assembly, Heat Shield			
			13	W11654045	Front Evaporator Cover, FC			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Refrigerator Door	7	W11095783	Endcap Trim, Door	13	W11654055	Gallon Door Bin
	W11654049	Right Hand	8		Door Self Lock	14	W11654057	Stadium Bin, Bottom Door Bin
2		Refrigerator Door		W11110855	Left Hand			FOLLOWING PARTS NOT ILLUSTRATED
	W11654050	Left Hand		W11110854	Right Hand			
3	W11654051	Mullion, Flipper, Door	9	W11110857	Stopper, Door		W10518672	Badge
4	W11430637	Control, Hera	10	W11306508	Seal, Vertical			
5	W11376604	Gasket, Door	11	W11654054	Horizontal Inner Door Seal			
6	W11394709	Assembly, Fascia	12	W11024885	Magnet, Switch			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Freezer Door	3	W11306327	Gasket, Freezer Door	4		Door Self Lock
	W11658538	Left Hand					W11110855	Left Hand
2		Freezer Door					W11110854	Right Hand
	W11658537	Right Hand				5	W11110857	Stopper, Door


REFRIGERATOR & FREEZER SHELF PARTS



REFRIGERATOR & FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11654066	Crisper Pan Assembly	4	W11654091	Center Support, Crisper Pan	7	W11047171	Assembly, Track Roller
2	W11654070	Assembly, Glass Shelf	5	W11654338	Pull Out Tray Assembly, FC	8	W11394971	Assembly, Pizza Rack
3		Crisper Pan Support	6	W11654332	Support Roller, Crisper Pan & Supports	9	W11654339	Bottom Drawer, RH, FC
	W11124470	Left Hand						
	W11654088	Right Support, Crisper Pan						


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11200488	Tube, Suction	7	W10805035	Drier (Service Drier Without Dye)	12	W11117895	Assembly, Filter Harness
2	W11029011	Tray, Evaporator			(Also Order the Following Lokring Parts)	13	W11083695	Cover, Compressor Roller
3	W11047160	Tube, Process		W10896689	5/4-NR-MS-00 (Heat Loop to Drier)	14	W11029075	Assembly, Drain Tube
4	W11208327	Compressor (Also Order the Following Lokring Parts)		W11313694	5/1.8-NR-MS-00 (Capillary Tube to Drier)	15	W11027538	Unit, Cover REFRIGERANT CHARGE 77.0 grams (R600a)
	W10895723	8/6-NR-MS-00 (Suction Tube to Compressor)		W10891060	4-NK-MS-00 (Heat Loop to Drier)			
	W10913906	6-NF-MS-SV-NG (Discharge Tube to Compressor)	8	W11027541	Plate, Compressor Base			
	W10895750	7/5-NR-MS-00 (High Pressure Side to Compressor)	9		Roller (Not Serviced)			
5	W11320585	Inverter	10		Bolt (Not Serviced)			
6	4387558	Grommet	11	W11368461	Cord, Power			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11397137	Assembly, Icemaker	3	W11394756	Tray, Ice	5	W11395429	Tube, Fill
2	W11366275	Water, Funnel	4	W11383473	Assembly, Water Valve	6	W11659196	Ice Maker Frame