


KitchenAid®

ELECTRIC RANGE

MODELS:

KSEG950ESS6 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15		Endcap	27	W11379947	Bracket, Anti-Tip
	W11509601	Use and Care Guide		W10555937	Stainless (Left)	28	W10664705	Bumper
	W11435572	Quick Start Guide		W10555940	Stainless (Right)	29	W10759325	Assembly, Display
	W11326899	Tech Sheet	16		Console	30	7201P077-60	Gasket, Infinite Switch
	W10817089	Downdraft Template		W10901116	Stainless	31		Console, Lower Panel
2	W11600012	Spring, Element	17	W10578768	Switch, Infinite (Right Rear)		W10743276	Stainless Bezel
3	3196178	Screw	18	W10437094	Switch, Infinite (Right Front and Left Rear)	32	W10663809	Stainless
4		Cooktop				33	W10558372	Bracket, Control
	W10669572	Stainless				34	W10437092	Switch, Infinite (Left Front)
5	W10275048	Element (3000 and 1400W)	19		Knob	35	W10882900	Gasket
		(Left Front)		W10823543	Stainless (Right Rear)	36	W10612719	Gasket, Console and Cooktop
6	W10248261	Element (1200W) (Right Rear)		W10823541	Stainless (Left Rear)			
7	W10251108	Element (3200W) (Right Front)		W10823538	Stainless (Right Front)			FOLLOWING PARTS NOT ILLUSTRATED
8	W10342780	Element (1300W) (Left Rear)		W10823530	Stainless (Left Front)		W11451596	Harness, Main
9	W10575593	Grill, Air	20	W10598048	Bracket, Console (Center)		W10575120	Harness, Keypad
10	W11175271	Bracket, Radiant					W11172426	Harness, Display
11	W10561812	Pan, Radiant	21	W10759299	Control MRC2		W11172418	Harness, Console
12	W10162253	Brace, Corner (Left)	22	W11355689	Keypad Shield		W11171878	Harness, Cooktop
	W10162252	Brace, Corner (Right)	23		Vent, Trim Top		W11198274	Harness, Down Draft Fan Jumper
				W10636529	Stainless		W10664316	Clip, Harness (Cooktop)
13	W10289169	Support, Cooktop (Right)	24	3196068	Lens, Indicator			
	W10289170	Support, Cooktop (Left)	25	W10555923	Bracket, User Interface			
14	3196173	Screw	26	7101P485-60	Screw, Anti-Tip Kit			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	22	W10828883	Bracket, Panel (Left)	43	W11467246	Cooling Fan
2	3196560	Screw		W10828882	Bracket, Panel (Right)	44	W11117035	Shield, Wire
3		Panel, Side	23	3196178	Screw	45	W10162241	Channel, Rear
	W10162245	Black	24	W11634772	Light Assembly	46	W10162248	Cover, Wire
4	3400029	Nut		W10571723	Bulb, Halogen 40 Watts	47	W11379354	Cover, Back
5	W11491752	Gasket, Door	26	3400016	Screw	48	W10686408	Kit, Reservoir (Steam Rack)
6	W10544952	Element, Broil	27	W10586204	Sensor	49	W10554007	Rack, Steam
7	W10774342	Element, Bake	28	3196169	Screw	50	W10554006	Rack, Maximum Capacity
8	W10362924	Screw	29	W10655441	Shield, Power Cord	51	W10911366	Rack, Sliding
9	W11122085	Assembly, Flue	30	W10031780	Screw	52	W10624592	Cord, Power
10	W10289168	Box, Burner SI	31	W10273192	Rod, Door Switch	53	7103P027-60	Nut
11	W10341186	Front Foot Assembly	32	9758701	Spacer, Door	54	W11510561	Barrier Rail, Rubber (Front Left)
12	W10067840	Screw	33	W10774446	Bottom, Oven		W11510562	Barrier Rail, Rubber (Front Right)
13	W10541959	Shield, Bake	34	W11511828	Switch, Door	FOLLOWING PARTS NOT ILLUSTRATED		
14	W10137382	Clip, Panel	35	W10281322	Kit, Bare Wire Adapter Block			
15	W10390008	Base Rail Assembly (Left)	36	W10603482	Rack, Ladder	W10289173	Insulation, Wrap	
	W10390007	Base Rail Assembly (Right)	37	W11353932	Convection Assembly	W10575374	Insulation, Bottom	
16	W10058460	Foot, Leveling	38	W10346153	Baffle, Full Convection	4820F015-59 Insulation, Strap		
17	3196548	Fuse, Thermal	39	W10273002	Bracket, Oven Support	W10162240 Insulation, Back		
18	3196172	Screw	40	W11379357	Bake Pan	7111P017-60 Clamp, Wire		
19	W10035900	Support, Oven Bottom	41	W10162255	Duct, Cover			
20	3186034	Bracket, Service	42	W10162254	Duct, Cooling			
21	W10246624	Block, Terminal						


BLOWER PARTS



BLOWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10661156	Enclosure, Blower	7	W10789391	Kit, Blower Installation	12	W10702071	Retainer
2	W10572224	Plenum, Intake	8	W10810492	Kit, Blower	13	W10759311	Gasket, Blower
3	W10572145	Plenum, Upper	9	W10788527	Assembly, Capacitor	14	W10642096	Adaptor, Exhaust
4	W10575379	Grease, Filter	10	W10787917	Cover, Capacitor	15	W10789390	Assembly, Plenum Support Bracket
5	W10575393	Guard, Filter	11	W10661835	Plenum, Side			
6	W10789431	Kit, Plenum Transition						

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door Handle
	W11669501	Stainless
2	9780274	Screw
3	W10518672	Badge
4	W10826568	Liner, Door
5	W10031790	Screw
6	W11223202	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10885519	Hinge, Door (Active)
8		Assembly, Outer Door
	W10634271	Stainless
9	W10541911	Bracket, Glass Upper Handle
10	W10327235	Screw
11	W10813140	Rail, Horizontal Support

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10031780	Screw
13	W11091878	Screw
14	W10813139	Rail, Vertical Support
15		Scoop, Door
	W10613791	Black
16	W10319024	Washer, Door
17	W11379948	Glass Spacer
18	W11440161	Bottom, Door Cover

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196169	Screw	3	W10318026	Bracket, Mounting
2		Panel, Drawer Front	4	8004P024-60	Spacer, Side Panel
	W10634248	Stainless	5	W11452957	Baffle, Drawer Panel

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit and Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS AND POLISHES
	31605	Kit, Cooktop Care
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10432539	Griddle
	W10432545	Kit, Grill TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless