


KitchenAid®

REFRIGERATOR

MODELS:

KUDR204KSB00 (Stainless)


CABINET PARTS



CABINET PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|---------------------------|-------------------|-----------------|----------------------------|-------------------|-----------------|---------------------------------|
| 1 | | Literature Parts | 6 | W11568769 | Cover Assembly, Evaporator | 12 | W11568794 | Assembly, Switch Box |
| | W11533205 | Use & Care Guide | | | | 13 | W11371097 | Screw |
| | W11537003 | Energy Guide | 7 | W11375760 | Screw | 14 | W11239541 | Grille |
| 2 | W11568787 | Connector, Cover | 8 | W11568776 | Cover Piece, Evaporator | 15 | W11371095 | Screw |
| 3 | W11359415 | Fuse, Temperature | 9 | W11568783 | Switch, Case | 16 | W11568948 | Assembly, Separator |
| 4 | W11568792 | Assembly, Trim | 10 | W11568786 | Switch, Door | 17 | W11312450 | Cover, LED |
| 5 | W11359416 | Defrost Holder and Heater | 11 | 4344763 | Leg, Leveling | 18 | | Cabinet (Not a Servicable Part) |


UPPER DRAWER PARTS



UPPER DRAWER PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|----------------------------|-------------------|-----------------|------------------------|-------------------|-----------------|---------------------------------|
| 1 | W11568830 | Top Foamed Door Assembly | 9 | W11568838 | Door Gasket, Short | 18 | W11422709 | Screw |
| 2 | W11568832 | Drawer Box Assembly, Upper | 10 | W10204808 | Screw | 19 | W11568932 | Wrap, Stainless |
| 3 | W11568835 | Mat, Upper Drawer | 11 | W11568839 | Plate, Door Handle | 20 | W10319185 | Screw |
| 4 | W11568836 | Drawer Partition | 12 | W11371095 | Screw | 21 | W11568934 | Insulation, Door |
| 5 | W10204920 | Nut | 13 | W11568936 | Control Panel Assembly | | | FOLLOWING PARTS NOT ILLUSTRATED |
| 6 | W10204810 | Screw | 14 | W11312450 | Cover, LED | W11576386 | | Complete, Door Assembly |
| 7 | W11568837 | Gasket, Door | 15 | W11568841 | Lamp Cover | | | |
| 8 | W11360665 | Gasket, Sash (Top/Bottom) | 16 | W11576360 | Harness | | | |
| | | | 17 | W11568842 | Support, Lead Wire | | | |


LOWER DRAWER PARTS



LOWER DRAWER PARTS

| <u>Illus.</u> <u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u> <u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u> <u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------------------|-----------------------------|-----------------|------------------------------|-----------------------------|-----------------|------------------------------------|
| 1 | W11568937 | Door Assembly, Lower | 9 | W11360665 | Gasket, Sash (Top/Bottom) | 18 | | Rail, Side |
| 2 | W11568938 | Drawer Box Assembly, Bottom | 10 | W11568838 | Door Gasket, Short | | W11568762 | Left Hand |
| 3 | W11568945 | Mat, Lower Drawer | 11 | W11568796 | Plate, Push | | W11568764 | Right Hand |
| 4 | W11568946 | Bottom Drawer Partition | 12 | W11371095 | Screw | 19 | 4344797 | Screw |
| 5 | W10204809 | Screw | 13 | W11422709 | Screw | | | FOLLOWING PARTS NOT ILLUSTRATED |
| 6 | W10204920 | Nut | 14 | W10772910 | Nameplate | | W11576925 | Complete, Door Assembly |
| 7 | W10204810 | Screw | 15 | W11568932 | Wrap, Stainless | | | |
| 8 | W11568947 | Gasket | 16 | W10319185 | Screw | | | |
| | | | 17 | W11568934 | Insulation, Door | | | |

UNIT PARTS



UNIT PARTS

| <u>Illus.</u> <u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u> <u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u> <u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|-----------------------------------|-----------------------------|-----------------|---------------------|
| 1 | W11576947 | Clamp, Cord | 10 | W11360536 | Assembly, Fan Motor | 18 | 4344780 | Bolt, Compressor |
| 2 | W11371097 | Screw | 11 | W10805035 | Drier (Service Drier Without Dye) | 19 | 4344779 | Grommet, Compressor |
| 3 | W11360241 | Water Pan, Evaporator | 12 | W11265569 | Clamp | 20 | W11498145 | Cord, Power |
| 4 | W11375763 | Screw | 13 | W11531824 | Compressor | | | REFRIGERANT |
| 5 | W11568810 | Main PCB | 14 | W11422771 | PTC Thermistor | | | CHARGE |
| 6 | W11577175 | Tag, Power Cord | 15 | W11568812 | Protector, Motor | | | 46 grams (R600A) |
| 7 | 4344826 | Screw | 16 | W11568820 | Cover | | | |
| 8 | W11265570 | Washer | 17 | W11360595 | Compressor, Rubber | | | |
| 9 | W11313206 | Cover, PCB | | | | | | |