




Dishwasher

MODELS:

MDB4949SKB3 (Black)
MDB4949SKW3 (White)
MDB4949SKZ3 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Panel, Front (Includes UI Insert, 4,11,13,14 &15)	11	W10692757	Barrel Nut, Front Panel
	W11323304	Owners Manual				12	W11438978	Screw, Black
	W11650513	Energy Guide		W11594024	Black		W11438977	Screw, White
	W11366143	Tech Sheet		W11594025	White	13		Handle
2		Arm, Hinge		W11594026	Stainless		W11242122	Black
	W11662392	Left Hand	7	3400000	Screw		W11242123	White
	W11662370	Right Hand	8	W11364953	Screw		W11242124	Grey
3	W11377160	Cross Brace, Door	9	W11038694	Insulation, Single Layer	14	W11491721	Housing, UI
4	W10612925	Badge						
5		Access Panel	10		Toe Panel			
	W11108979	Black		W11467733	Black			
	W11110746	White		W11467726	White			


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Cap	7	W11025634	Bezel, Vent	14	W11092649	Dispenser Assembly
	W11591426	Black	8	3400071	Screw	15	W11050927	Seal, Console/Door
	W11591427	White	9	W10348409	Screw	16	W11088985	Hanger, Control
2	W11084865	Jumper, Door	10	W11098822	Inner Door Assembly	17	W11527847	Vent Assembly
3	W11258418	Screw	11	W11563231	Seal, Door Bottom	18	W11397505	Fuse, In-line
4	W10711884	Screw (Long)	12	W11649439	Wiring Harness, Main (Includes Thermostat & Fuse)	19	W10348408	Screw
5	W11091934	Latch Assembly (Includes Switch)	13	W11084845	Wiring Harness, Inner Door			
6	W11648213	Control, Electronic						


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10920228	Tub Assembly (Includes Gasket)	13	W11036170	Float Switch	23	W11048217	Tub Mount, Upper Rack
2	W11226744	Base, Terminal Box	14	W11184083	Plug, Tub	24	W11362501	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
3	W11035860	Gasket, Tub	15	W11429970	Water Inlet Assembly			
4	W11429974	Nut, Water Inlet	16	W11455395	Leg, Leveling			
5	W11090487	Strike, Latch	17	3378128	Washer, Pronged Cup			
6	W11296374	Screw	18	3400014	Screw, Grounding	25	W11132441	Terminal Block
7	W11165091	Seal, Cabinet	19	W10277003	Screw	26	W11536143	Heater Element Assembly
8	W11025993	Drip Tray	20	W11226746	Cover, Terminal Box	27	3400892	Screw
9	W11025986	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025988	Funnel Extension		W10920122	Left Hand			
11	8269145	Bracket, Undercounter		W10920120	Right Hand			
12	W11165093	Cover, Tub Corner	22	W11655286	Shield, Tub Sound			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11633255	Pump Assembly	14	W11491436	Motor, Drain	26	W11036143	Clip, Hose
2	W11294352	Isolator, Front Motor	15	W11131184	Hose, Drain	27	W10466656	Clamp, Hose
3	W10891545	Diffuser, Inlet	16	W10903468	Disc, Diverter	28	W11036287	Hose, Inlet
4	W11294350	Hanger, Front Motor	17	W11025963	Bracket, Rear Motor	29	W11236576	Clamp, Hose
5	9741232	Screw	18	W11418271	Fastener	30	W11039864	Grate
6	W10891547	Check Valve, Drain	19	W11126174	Indicator, Optical Wash	31	371505	Clamp, Hose
7	W11048456	Wash Arm Assembly	20	370445	Clamp, Hose	32		Diverter Valve Motor (Not Serviced)
8	W11495337	Filter Assembly	21	W11163419	Bracket, Thermostat	33	W11034556	Sump (includes Seal and Diverter)
9	W10380239	Ring, Volute	22	W11193089	Thermostat (Included with Main Wiring Harness)			(Includes 3, 5 & 32)
10	W11633261	Motor & Sump Assembly	23	W11025970	Fill Valve Assembly	34	W10467002	Screw
11	W11036663	Isolator, Rear Motor	24	W11122851	Clamp, Hose	35	W10753070	Capacitor
12	W11250985	Hose, Pressure	25	W11036161	Hose			
13	W10900387	Hose, Suction						


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11507999	Feed Tube Assembly	3	W11039869	Sprayarm, Third Level	5	W11128231	Cover, Diverter
2	W11039888	Retainer	4	W11174340	Upper Sprayarm Assembly	6	W10892836	Retainer, Docking (2nd Level)


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10847875	Dishrack, Upper	4	W11084872	Track Stop, Rear	7	W11129799	Cupshelf Assembly
2	W11441109	Track, Dishrack	5	W11084874	Track Stop, Front	8	W11048219	Wheel
3	W11129797	Clip, Cupshelf	6	W11133748	Mount Assembly			

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525641	Dishrack, Lower	3	W11281126	Silverware Basket Assembly
2	W11133747	Wheel & Transport Assembly	4	W11267705	Lid, Silverware Basket (Side)

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396277	Barrier Kit
	W11381654	External Drain Hose, 12 FT
	W11365011	Power Cord Kit (Straight)
	W11365014	Power Cord Kit (Right Angle)
	4396672	Strain Relief, Power Cord (Metallic)
	W10685193	Compression Hose Fitting, Water Line
	W10278635RP	Fill Hose Kit