




**ELECTRIC DRYER  
(Residential Commercial-Grade)**

**MODELS:**

MEDP586KW0 (White)


# TOP AND CONSOLE PARTS



# TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W10286180	Cover, Terminal Block	16	W11613271	Switch, Push-To-Start
	W11601604	Installation Instructions	8	3390631	Screw	17	W11551565	Harness, Main
	W11601607	Use and Care Guide	9	W11547354	Fascia	18	W10476828	Control, Electronic
	W11601605	Wiring Diagram	10		Knob	19		Top
	W11601608	Quick Start Guide		W11567082	Stainless		W10772880	White
2	W11124005	Console	11	W11547331	Bracket, Back	20	W10836097	Panel, Dampening
3	W10131123	Nut, "U"	12	8533971	Screw			
4	W10386302	Screw	13	W10185992	Timer Assembly (60 Hz.)			
5	W10863352	Panel, Rear (Console)	14	694419	Buzzer, Mini			
6	3390647	Screw	15	8578352	Switch, Rotary (5 POS)			


# CABINET PARTS



# CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Cabinet	17		Panel, Toe	35	343641	Screw
	W11161907	White		697215	White	36	3397659	Block, Terminal
2	W10773242	Screw	18	3388229	Retainer	37	3393008	Screw
3	3391846	Clip, Front Panel	19	W10836097	Panel, Dampening	38	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
4	3391915	Screw	20	W10344193	Pulley-Idler Assembly			
5	W10291934	Clip	21	3389420	Screw			
6	W10073890	Leveling Leg Assembly	22	W10446781	Spring, Idler	39	279393	Screw Kit, Terminal Block
7	W10569603	Switch, Door	23	W10131172	Belt, Drive			
8	697773	Screw	24	660658	Clamp, Motor	40	8281212	Screw
9		Front Panel	25	W10396031	Motor	41	W11378153	Cover, Terminal
	W10694688	Panel, Front	26	3394341	Pulley, Motor	42	3390631	Screw
10	W11224633	Strike, Door	27	3393657	Restrainer, Belt	43	W11590485	Foot, Dryer Adapter
11	W10879744	Screw	28	3387118	Bracket, Motor			
12		Plug, Hinge	29	8066134	Switch Assembly			
	W10191265	White	30	3394881	Switch, Belt			
13	3387242	Seal, Front Panel	31	8066120	Lever, Belt Switch			
14	345670	Lock Top	32	3398948	Wire, Jumper (Broken Belt Switch)			
15	3357011	Screw	33	W10167612	Wire, Belt Switch			
16	693152	Bumper	34	98129	Screw			


# BULKHEAD PARTS



# BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread	18	3387459	Washer	37	W10349492	Wheel, Blower
2	90767	Screw	19	W10359272	Shaft, Drum Roller - Left Hand Thread	38	W10345456	Clip, Spring
3	3390647	Screw	20	W10512946	Washer, Tri Ring	39	697557	Bulkhead, Front
4	3357011	Screw	21	W10314171	Roller, Support	40	697770	Seal, Plate Cover
5	W11104018	Assembly, Air Duct	22	3387223	Sensor, Electrode	41	3392519	Fuse, Thermal (91C)
6	8066099	Bracket, Heater Box	23	W10692558	Grill, Outlet	42	8318268	Thermostat
7	697814	Seal, Drum Front	24	W10685669	Assembly, Outlet Housing	43	W10891205	Assembly, Weld Heater Box
8	3934666	Nut, Hex	25	W10545923	Assembly, Drum	44	8544362	Housing, Blower
9	W10298258	Harness, Sensor	26	W10219342	Screw	45	8066168	Assembly, Lint Duct
10	3402841	Lens, Drum Light	27	W10521118	Seal, Drum	46	279973	Kit, Thermal Cut-Off (Includes Thermostat)
11	693995	Screw	28	697693	Baffle, Drum	47	3391914	Thermostat HL-295/215
12	3387230	Screw	29	8572105	Clip, Exhaust			
13	W10049370	Screen, Lint	30	8533971	Screw			
14	3387747	Element, Heater	31	489463	Screw			
15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	32	8066224	Pipe, Exhaust			
16	W10001120	Nut, Hex (Left Hand Thread)	33	3406124	Bulb, Light			
17	W11162455	Bulkhead, Rear	34	695240	Screw			
			35	8578825	Bracket, Drum Light			
			36	W10214261	Socket, Light			

# DOOR PARTS





# DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Outer Door	4		Door, Inner	9	690081	Assembly, Door Catch
	W10284127	White		W10470571	White	10	W10192860	Screw
2		Assembly, Inner Door	5	3393258	Screw	11		Hinge & Pin Assembly
	W10513690	White	6	W10284121	Glass, Door		W10279703	Silver
3	W10354795	Seal, Door	7	W10284122	Seal, Window	12	342055	Screw
			8	8519354	Retainer, Window			

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS|THE FOLLOWING POWER CORD CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord