




ELECTRIC RANGE

MODELS:

MER4800PZ1 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	W10275048	Element (3000 and 1400W)	10	7101P485-60	Screw, Anti-Tip Kit
	W11637853	Owners Manual			(Left Front)	11	W10691223	Pan, Radiant Element
	W11637854	Quick Start Guide						FOLLOWING PARTS NOT ILLUSTRATED
	W11390998	Tech Sheet	6	8273994	Element (1200W)			
2	W11600012	Spring, Element			(Left Rear and Right Rear)		W11452624	Harness, Main
3	W10607641	Bracket, Cooktop (Left)	7	W10248262	Element (2500W)		W11134603	Harness, Cooktop (Left)
	W10607642	Bracket, Cooktop (Right)			(Right Front)		W11134551	Harness, Cooktop (Right)
4		Cooktop	8	W11668631	Element, Warm Zone (Center)		W11598759	Harness, Warm Zone
	W11022824	Black	9	W11379945	Bracket, Anti-Tip			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6		Control, Electronic (LCX)	12	3196169	Screw
	W11130372	Black (Left)				13	3196165	Screw
	W11130379	Black (Right)		W11527164	Black	14	3148951	Switch, Infinite
2	W10695491	Bracket, Control	7		Knob			(Left Rear and Right Rear)
3		Panel, Console		W11636183	Stainless			
	W10885607	Stainless	8	W10134247	Shield, Heat	15	3148954	Switch, Infinite (Orange)
4	W10434452	Switch, Infinite (Dual)	9	3400882	Screw			(Right Front)
		(Left Front)	10	8272473	Cover, Upper Rear			
5	3196178	Screw	11	W10525121	Bracket, Console Mounting			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	15	W10390008	Base Rail Assembly (Left)	27	W10181986	Sensor, Oven
2	3196154	Screw				28	3196169	Screw
3		Panel, Side		W10390007	Base Rail Assembly (Right)	29	W10326122	Cover, Terminal Block
	W10162245	Black				30	W10031780	Screw
4	3400029	Nut	16	W10058460	Foot, Leveling	31	W11173792	Rack, Oven
5	W10129032	Seal, Door	17	3196548	Fuse, Thermal	32	W10910404	Counterweight
6	9757340	Element, Broil	18	3196172	Screw	33	3196560	Screw
7	W11111743	Element, Bake	19	W10404688	Clip, Oven Support	34	W11510560	Barrier Rail, Rubber (Left and Right)
8	W11034869	Screw	20	3186034	Bracket, Service	35	W11464547	Bracket, Front Frame
9	W10134285	Tube, Vent	21	W10245259	Block, Terminal			
10	W10674705	Glide, Drawer Front	22	W10281322	Kit, Bare Wire Adapter Block			FOLLOWING PARTS NOT ILLUSTRATED
11	W10341186	Front Foot Assembly	23	3196178	Screw		8273263	Insulation, Wrap
12	W10067840	Screw	24	W11634772	Light Assembly		8272611	Insulation, Back
13	8054068	Retainer, Insulation	25	W10571723	Bulb, Halogen 40 Watts		W10333344	Insulation, Flue
14	W10137382	Clip, Panel	26	3400016	Screw			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Vent	9		Glass Assembly, Outer Door	15	W10200660	Screw
	W11047800	Stainless				16	W11628148	Badge
2	W10480830	Screw		W11620248	Stainless	17	W11440159	Trim, Bottom Door
3		Handle, Door	10		Trim, Side			
	W11495825	Stainless		W10746436	Black (Left)			
4	9761344	Liner, Door		W10746435	Black (Right)			
5	W10031790	Screw	11	W10327235	Screw			
6	W11367326	Glass, Inner	12	W10299227	Hinge, Door (Passive)			
7	W11380221	Retainer, Insulation	13	W10031780	Screw			
8	W10440013	Hinge, Door (Active)	14	W11379944	Strap, Door			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	2	W10688022	Drawer, Storage	4	W10674708	Glide, Drawer Rear
	W11449698	Stainless	3	W10462910	Bracket, Mounting Drawer	5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting