




**GAS RANGE**

**MODELS:**

MFGS4030RB0 (Black)  
MFGS4030RW0 (White)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7		Grate Kit	19	W11637551	Spring, Clip
	W11641830	Quick Start Guide		W11601432	Black (Set of 2)			FOLLOWING PARTS NOT ILLUSTRATED
	W11642080	Owners Manual	8	W10673618	Screw			
	W11639171	Tech Sheet	9	9780274	Screw		W11374164	Harness, Main
2		Burner Cap Kit	10	W11379945	Bracket, Anti-Tip		3196173	Screw
	W11636608	Black (Set of 4)	11	7101P485-60	Screw, Anti-Tip Kit		W11448086	Harness, Bake and Broil
3	W11352019	Spreader, Flame (Left Front and Right Rear)	12	W11672010	Grate, Bumper		3196520	Clip, Wire
	W11352021	Spreader, Flame (Left Rear)	13	W11357363	Oval Burner Assembly		313438	Clip, Harness
	W11352018	Spreader, Flame (Right Front)	14	W11635708	Burner Kit		3196896	Clip, Wire
4		Cooktop		W11402711	Black (Left)			
	W11279786	Black		W11402710	Black (Right)			
5		Panel, Manifold		W11402708	White (Left)			
	W11412237	Black		W11402707	White (Right)			
	W11412238	White	16	W11366598	Bracket, Spark Module			
6		Knob, Control	17	W11367962	Frame, Cooktop			
	W11584000	Stainless	18	W11295628	Cooktop, Front Bracket			


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	W11285475	Bracket, Mounting	8	3196178	Screw
	W11625423	Black (Left)	5	W10818365	Module, Spark DSI	9	W11371599	Bracket, Control
	W11625420	Black (Right)	6		Panel, Lower	10	W11624054	Cover, Back
	W11625422	White (Left)		W11625443	Black	11	W11350452	Spark Module
	W11625418	White (Right)		W11625439	White	12	3196169	Screw
2	W11363806	Shield, Heat	7		Control, Electronic (LCX)			
3		Panel, Control		W11637093	Black			
	W11730187	Black						
	W11730186	White						


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10827923	Electrode, Spring	4	W11384792	Tubing (Manifold to Regulator)	16	W11428831	Electrode (Left Front and Left Rear)
2	W10849716	Orifice (12K) (Left Front and Left Rear)	5	W11637977	Harness, Igniter (Includes Switches)		W11428858	Electrode (Right Front, Right Rear, and Center)
	W10849722	Orifice (18K) (Right Front)	6	W11450459	Electrode, Bake	17	W11402213	Screw
	W10849719	Orifice (5K) (Right Rear)	7	W11279814	Manifold Assembly	18	3196265	Screw
	W10907868	Orifice (10K) (Center)	8	W11630470	Valve, Gas (Left Front and Left Rear)	19	W10362924	Screw
3	W11300876	Orifice Holder Assembly (12K) (Left Front)		W11279839	Valve, Single (Right Front and Center)			FOLLOWING PARTS NOT ILLUSTRATED
	W11341430	Orifice Holder Assembly (12K) (Left Rear)		W11279837	Valve, Single (Right Rear)		W10838304	Orifice, LP Bake
	W11300879	Orifice Holder Assembly (18K) (Right Front)	9	W10224921	Bracket, Aegis		W11370715	LP 5 Orifice Conversion Kit
	W11300867	Orifice Holder Assembly (5K) (Right Rear)	10	3196385	Screw			
	W11300874	Orifice Holder Assembly (10K) (Center)	11	3400016	Screw			
			12	W10714060	Element, Broiler			
			13	W10184491	Spreader, Flame (Oven)			
			14	9758078	Burner, Bake			
			15	W10818355	Regulator			

# CHASSIS PARTS






# CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11366110	Box, Flue	14	8053969	Shield, Heat	24	3196169	Screw
2	W11279866	Shield, Flue	15	W11640074	Shield, Lower	25	W11661976	Cord, Power
3	W10379120	Screw	16	W10390008	Base Rail Assembly (Left)	26	W10289077	Receiver, Hinge
4		Panel, Side				27	W11511828	Switch, Door
	W11445467	Black		W10390007	Base Rail Assembly (Right)	28	W11634772	Light Assembly
	W11445761	White				29	W10571723	Bulb, Halogen 40 Watts
5	W10137382	Clip, Panel	17	9757239	Rod, Door Switch			
6	W11287215	Bracket, Cooktop Console	18	W10031780	Screw	30	W11464547	Bracket, Front Frame
			19	3400080	Screw	31	W11173792	Rack, Oven
7	W10362924	Screw	20	W10674705	Glide, Drawer Front			FOLLOWING PARTS NOT ILLUSTRATED
8	3196178	Screw	21	W10129032	Seal, Door			
9	W10341186	Front Foot Assembly	22	W10435470	Brace, Main Back		W10818362	Insulation, Wrap
10	W10058460	Foot, Leveling	23	W11379353	Retainer, Insulation (Left)		W11632402	Insulation, Back
11	W11602073	Bottom, Oven						
12	W10586204	Sensor		W11379943	Retainer, Insulation (Right)			
13	8053967	Baffle, Burner Oven						

# DOOR PARTS




# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door
	W11495825	Stainless
2	W11628148	Badge
3	W10299226	Hinge, Active
4	9761344	Liner, Door
5	W10031790	Screw
6	W11367326	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W11157607	Bracket, Handle Mount (Right)
	W11417442	Bracket, Handle Mount (Left)
8	W10031780	Screw
9	W11686928	Retainer, Insulation
10	W10299227	Hinge, Door (Passive)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11		Glass, Outer Door
	W11631958	Black (Includes Badge)
	W11631956	White (Includes Badge)
12	3196154	Screw
13	W10327235	Screw

# DRAWER PARTS



# DRAWER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10674708	Glide, Drawer Rear	4		Panel, Drawer Front	6	3196169	Screw
2	W10688022	Drawer, Storage		W11123976	Black	7		Rivet, Push
3	W10462911	Bracket, Mounting		W11123977	White		3196813	Black
			5	3196178	Screw		3196814	White

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		FOLLOWING PARTS NOT ILLUSTRATED
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	285006	Black
	350930	White
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	30-48KITRC	Gas Range Connector Kit
	4396096RB	Griddle
	4396923	Broiler Pan and Grid