




**AUTOMATIC WASHER
(Residential Commercial-Grade)**

MODELS:

MVWP586GW0 (White)


TOP AND CABINET PARTS



TOP AND CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	11		Bezel, Lid Lock	27	W11203364	Hose, Outer Drain Assembly
	W11600470	Installation Instructions		W10392041	White	28	W10280024	U-Bend, Drain Hose
	W11600465	Use and Care Guide	12	21258	Bearing, Lid Hinge	29	356138	Clamp, Hose
	W11602327	Tech Sheet	13	90016	Clip, Harness	30	W10339879	Tie, Cable
	W11600466	Quick Start Guide	14	W10482836	Latch, Lid Lock Assembly	31	54583	Hinge, Lid Right Hand
	W11626976	Energy Guide	15	W10588613	Screw	32	W10660565	Screw
2		Top	16	W11417173	Panel, Rear	33	90406	Nut, Cage
	W10461170	White	17		Cabinet	34	W11129581	Bracket, Front Top
3		Assembly, Lid and Bumper	18	W10845574	White	35	W10161707	Top, Foam Seal
	W10251302	White		W10724131	White	36	W11610868	Bracket, Base
4	W11241723	Bumper, Lid	19	W11089573	Brace, Cabinet Top - Rear	37	W11552072	White
5	9740848	Screw				38	W10866521	Bracket, Front Panel
6	91770	Hinge, Lid (Left Hand)	20	W10567155	Screw	39	8283273	Damper, Brace
7	W10119872	Screw	21	W10461182	Lock, Top	40	W10862638	Lock, Top Front
8		Strike, Lid Lock	22	W10245373	Foot, Leveling	41	W11096159	Damper, Sound
	W10240513	White	23	W10461176	Hinge, Top	42	W10866523	Rivet
9	W10273971	Screw	24	W10142728	Screw	43	W10192089	Dispenser, Bleach
10	3359452	Nut, Hex	25	W10461180	Cover, Harness	44	W10879744	Screw
			26	3400076	Screw			


CONTROLS AND WATER INLET PARTS



CONTROLS AND WATER INLET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11547599	Fascia	10	W11549786	Push Button, Start	22	W10843398	Harness, Valve
2	W10131119	Screw	11	W11124005	Console	23		Hose, Water Inlet
3		Assembly, Timer Knob	12	W10660565	Screw		W10852720	Cold Water
	W11567085	Knob (Stainless)	13	W10131123	Nut, "U"		W10852721	Hot Water
4	W10510149	Bezel - PTS	14	W10461159	Panel, Console Rear Cover	24	W10242307	Washer, Hose
5	W11547593	Bracket, Back						
6	W10285512	Switch, Rotary Encoder (4 Position)	15	W11108620	Harness, Jumper			
			16	W10694676	Harness, Upper VMW			
7	W10285518	Switch, Rotary Encoder (5 Position)	17	W10916256	Cord, Power			
			18	3400076	Screw			
8	W11617028	Control Unit Assembly, Machine & Motor	19	W10843661	Harness, Upper			
			20	W11032871	Relay			
9	90767	Screw	21	W10843663	Inlet Assembly, Water			


BASKET AND TUB PARTS



BASKET AND TUB PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10860509	Dispenser, Fabric Softener	12	W10908157	Screw	22	W10821954	Damper Assembly, Tub Suspension (Set Of 4-Includes Suspension Bushings and Suspension Balls)
2	358912	Seal, Cap	13	W10715783	Base, Agitator			
3	W10003790	Screw and Washer	14	W10556325	Tub Ring			
4	3949550	Washer	15	W11436991	Basket Assembly			
5	W10715784	Retainer, Cam	16	8533953	Screw	23	W10238301	Tub
6	W10782372	Assembly, CAM Complete	17	W10396887	Hub - Driven, Basket	24	W10843660	Harness, Lower (Includes Pressure Hose)
7	8055141	Bearing, Cam	18	W11284133	Retainer, Drive Block			
8	3366877	Dog, Agitator Clutch	19	W10215093	Filter, Drain Pump	25	W10531633	Hose, Pressure Switch
9	8055142	Agitator, Cam	20	8533928	Screw	26	W10005430	Clamp, Cable
10	W11182552	Auger, Agitator	21	W10839119	Strap, Snubber	27	8533943	Screw
11	W10715787	Couple, Agitator						

GEARCASE, MOTOR AND PUMP PARTS



GEARCASE, MOTOR AND PUMP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10276397	Pump Assembly, Drain	6	W10249633	Screw	12	W10625042	Capacitor, Motor Run
2	W10004910	Screw	7	W10850134	Motor, Drive	13	W10427633	Shield, Pulley Cover
3	W10763078	Hose, Inner Drain Assembly	8	W10094780	Screw	14	357640	Screw
4	8317496	Clamp, Hose	9	W11495180	Belt, Drive	15	W10721967	Splutch Kit (60Hz)
5	W11261591	Assembly, Gearcase	10	W11112160	Actuator, Shift			
			11	9741052	Screw			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

SEALER

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10135699	Affresh® Washer Cleaner
	8212526	Washer, Drip Tray
	W10576550	Main Top Rear Support

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

WATER SYSTEM PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10575888	Hose Fill Kit
	285834	Siphon Break Kit
	285835	Connector Assembly
	285863	4' Drain Hose w/Clamp
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	350008	Hose, Inlet (10')
	76314	Hose, Inlet (6' Hose With Elbow)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)