

Get started with your **Gas cooktop**

BEFORE YOU START



REMOVE PACKAGING

Remove all packaging material and tape. Check out your Use & Care Manual for tips to help care for your cooktop.





USE A COOKTOP CLEANER

Apply a cooktop cleaning cream to the cooktop and buffing with soft, clean cloth.



SET UP YOUR COOKTOP

Make sure your burner caps are centered on the burners and the cooking grates are in place.



USING YOUR COOKTOP

GAS BASIC.



Choose your cookware

Cookware should have flat bottoms that make direct contact with the entire surface burner grate.



Find the best burner to use


Small burners are best used for low heat or small amounts of food in small pans. Standard burners are great for most cooking needs. Use the largest burner when heating up large pots of liquid or food.



Set the right flame size


Set the flame size appropriately for the pan.

Be careful to not allow flames to extend beyond the outer edge of the pan.




KNOB LIGHTS.

Each control knob features a backlight that indicates whether a cooktop surface element is ON or HOT.



A white glow means the element is ON.



A red glow means the element is HOT.

The red backlight will glow when the element is still hot enough to cause burns and will remain on after the element is turned off until the surface has cooled to a safe temperature.



REMEMBER

- Be careful! Surface elements may be hot even though they appear cool.

QUICK CARE

Cleaning the cooktop



Protect your cooktop by quickly cleaning up spills when they happen. Before cleaning the cooktop, be sure the controls are turned OFF and the cooktop is cool. Use cleaning products that have been specifically designed for ceramic glass cooktops. You can also use a soft cloth, mild dish detergent and water or a 50/50 solution of vinegar and water. Refer to your Use & Care Manual for more care and cleaning recommendations.

Cleaning the knobs



Remove knobs from the cooktop before cleaning. Using a soft cloth, clean knobs with mild dish detergent and water or a 50/50 solution of vinegar and water. Refer to your Use & Care Manual for special instructions on how to remove and reinstall the knobs on the cooktop.

A little love goes a long way



Quick ongoing care keeps your range working great for years to come! Clean with warm water and mild soap, or try our line of Frigidaire ReadyClean™ cleaners, available on our website.



FAQs

My cooktop is brand new — why doesn't my cooktop work?

Your installer may have left the lever for the gas supply off while working to set up your range. Check out the installation instructions for how to turn the lever back on.

Why are there streaks or metallic marks on my cooktop?

Sliding or scraping of metal utensils on cooktop surface can cause streaks or metallic marks to form. To avoid this, do not slide metal utensils on the cooktop surface. Remove marks by applying a cooktop cleaning creme and buffing with a non-abrasive cloth or sponge.

How do I clean the knobs?

First, be sure to remove the knobs from your cooktop before cleaning. Do not place knobs in the dishwasher or soak them. Instead, clean the knobs with a soft cloth and mild dish detergent and water or a 50/50 vinegar and water solution.

Where can I get a propane conversion kit for my new gas cooktop?

You can get one at Frigidaire.com. Don't forget to have it installed by a qualified professional!

 Find more troubleshooting tips in the back of your Use & Care Manual and Frigidaire.com.

LET'S MAKE IT OFFICIAL!

Take the first step to becoming a part of the Frigidaire family by registering your new cooktop.

Look for the "SIMPLY SCAN TO REGISTER" label on your appliance or refer to the supplied registration card.

WE ARE
here
FOR YOU



Have a question?



Want help?



Need service?

owner support

frigidaire.com 1 (800) 374-4432

frigidaire.ca 1 (800) 265-8352

