








# Congratulations on your new GE Profile Combo !

## What to expect when using your Combo


- 
**No load transfer!** Start a load before work, before you go to bed...or anytime.
  - When you choose **WASH** + **DRY**, your work is done. The Combo will wash and then gently dry your garments in just a couple hours. Finally, laundry is **One & Done**.
- 
**Clothes may feel a little damp when the dry cycle ends, but they're actually dry.**
  - Because your Combo dries clothes at low heat in a sealed drum, they may feel slightly damp or cool on first touch. Just take them out & shake them and they will feel dry in a few seconds.
- 
**Wash + Dry a load in just a couple hours. Times may adjust before & during cycles.**
  - Your Combo learns your load patterns, fabric types and habits. You may notice that the total cycle time will adjust during a cycle and from load to load based on load size, soil level and spin out after wash.
- 
**Easy access dual-stage lint filter ensures high efficiency airflow.**
  - Recirculating filtered, high speed air-flow allows the Combo to deliver great drying performance. You'll notice that less lint is generated through air tumbling versus standard dryers. Look for reminders to clean the filter.
- 
**Simple to use with plenty of options! Explore all the features.**
  - Don't mess with detergent & softener: **SmartDispense**.
  - Start the Combo from your phone: **Remote Start**.
  - Increase dryness level of your laundry: **More Dry**.
  - Reduce wrinkles at end of cycle: **Wrinkle Care**.
  - ¿No hablas inglés? : Cambiar **Language** en el **Menu**.
  - Toss in a dryer sheet: **Wash Complete**  tells you when.

## How do I get started ?


**A** Remove shipping bolts, grommets & brace




**B** Level the Combo by adjusting the four legs and locking the clench nuts.




**C** Connect the hoses to the hot and cold water inlets.




**D** Connect the proper hot and cold hoses to the faucets and insert the drain tube into the standpipe.



**E** A simple 120V outlet is all the Combo needs. No 240V outlet needed! No external venting! It could go virtually anywhere.




**F** Connect the Combo using SmartHQ to your home wifi to enable updates & additional features.




## Keep your Combo in top shape


Installation on a riser




Cleaning the filter




Self Clean cycle



Clearing the drain pump




Register your Combo



# UltraFast Combo: The Only Machine You Need.

## Basic Operation of your Combo



- 1** Power On the Combo & load it with sorted laundry items.
- 2** Check the filter on both sides.

To get the best drying efficiency, it's important to start with a clean filter.
- 3** Select a Wash + Dry cycle.

If desired, you can choose to run a Wash or Dry only.
- 4** Manually dose or use SmartDispense after filling with detergent and/or softener. Choose other Wash and Dry Options as desired.
- 5** When ready, tap the Start / Pause button and let the Combo do both the washing & drying, thanks to no load transfer.
- 6** If desired, check the SmartHQ app on your phone for notifications, to adjust options, add more dry time or to learn more about the Combo.

## Advanced Features of your Combo

### Timed Dry

Switch from Sensor to Timed Dry and adjust time in 15 min increments.

### Downloaded Cycles

Use SmartHQ to add specialty cycles: Jeans; Air Fluff; Swimwear; or, PowerClean.

### Wash Complete



### My Settings



### Change Language

The Combo can provide messages & cycle info in English, Spanish or French.

### Dewrinkle

Help remove wrinkles from 1-8 dry garments using steam vapor and a gentle tumble.

### EcoCool™ Cycle

For a cold water clean equal to a Normal warm wash, try the EcoCool low energy cycle.

### Display & Sound Settings

Adjust screen brightness and signal volume right from the Menu.

### More Water

Add an extra 3 gallons of water for wash and each rinse at the touch of a button.

### Remote & Delay Start



### Adaptive SmartDispense™



### Eco Dry

From the Menu, turn Eco Dry mode ON to reduce the dryness level and use less total energy.

### Cycle / Energy Monitoring

Use SmartHQ to get info on cycle history and energy usage.



This is smarter cleaning.