

QUICK INSTALLATION GUIDE

Super Premium Built-in Refrigerator/Freezer Columns



STEP 1

Allow Refrigerator to Rest Before Use

- Wait **24 hours** before turning on the refrigerator.
- This ensures the compressor oil settles properly, especially if the unit was transported lying down or at an angle.
- **Important:** Skipping this step may damage the compressor and affect cooling performance.

STEP 2

Install the Anti-Tilt Bracket

(see installation manual: pages 6, 7 and 23)

- Mount the anti-tilt bracket securely to prevent the refrigerator from tipping.

STEP 3

Leveling and Door Alignment

(see installation manual: page 9)

- Ensure all leveling feet are properly adjusted to stabilize the refrigerator.
- Accurate leveling is critical for preventing operational issues and ensuring proper door alignment.

STEP 4

Align the Custom Panel

(see installation manual: pages 11 to 17)

- Custom panel weight can affect door sealing.
- Use the adjustment points provided to align the panel and ensure a proper seal. If the product is installed to the incorrect depth within the cabinet niche, the door will not make an effective seal or may not open properly.

STEP 5

Handle Installation (If Applicable)

- Install the handle kit, making sure to apply the provided Loctite thread locker during installation to prevent loosening over time.
- Refer to the handle installation instructions included in the kit:
For Stainless Steel Panels: Follow the specific guidelines.
For Wood Panels: Use threaded inserts for wood. For multiple installations, ensure correct handle alignment.

STEP 6

Inspect Water Line Connections

(see installation manual: pages 8, 9 and 25)

- After connecting the water line, inspect all connectors and hoses for leaks.
- Perform this step **before sliding the refrigerator into its niche** or securing it to adjacent cabinetry.
- **Important:** Fix leaks immediately to avoid damage to floors or cabinets.

STEP 7

Activate the Ice Maker (If Applicable)

(see installation manual: page 25)

- After installation, turn on the ice maker to enable ice production.

STEP 8

Install the Water Filter (If Applicable)

(see installation manual: page 25;
see user manual: pages 27, 28)

- Before turning on the automatic ice maker, ensure that the water filter cartridge is installed. Replace the filter regularly as indicated in the user manual.
- If the water supply is already filtered through a centralized system, the cooling unit can be set in water filter bypass mode by removing the filter cartridge.



Français



Español