




24" ELECTRIC BUILT-IN COOKTOP

MODELS:

WCE55US4HB00 (Black)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9		Knob, Control	13	4455917	Bracket, Cooktop Mounting
	W11206696	Instructions, Installation		W11130625	Black	14	3400093	Screw
	W11245478	Instructions, Undercounter Installation	10	W10578768	Switch, Infinite (Left Front & Right Rear)	15	7101P426-60	Screw
	W11206695	Guide, Use & Care		W10843843	Switch, Infinite (Left Rear)	16	7101P309-60	Screw
	W11206672	Diagram, Wiring Cooktop		W10437092	Switch, Infinite (Right Front)	17	W11177345	Top, Foam (Heat Shield)
2	W11120969	Black						FOLLOWING PARTS NOT ILLUSTRATED
3	W11215836	Plate, Switch	11	8273994	Element (1200W) (Left Front & Right Rear)	W11110594		Harness, Main
4	W11102060	Shield, Switch Plate				3192439		Seal, Limiter
5	W10225448	Spring, Element		8273993	Element (1800W) (Left Rear)	8286642		Tape, Foam
6	W11175314	Rail, Vertical		W10275049	Element (2500/1200W) (Right Front)	W11160363		Insulation, Cooktop (Knob)
7	W10293874	Grommet Black						
8		Box, Burner (Not Serviced)	12	3183956	Seal, Switch Cover			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	WA906B	Scraper, Cooktop
W10355051		Cleaner, Cooktop
	31464	Cleaner, Cooktop
	31463	Protectant, Cooktop
	242905	Kit, Canning Unit
	31605	Kit, Cooktop Care