




**GAS COOKTOP**

**MODELS:**

WCGK7530PS01 (Stainless)


# COOKTOP, BURNER AND GRATE PARTS



# COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11352195	Flame Spreader (Left Front and Center)	14	W10598131	Foot Pad, Grate (Outer)
	W11613935	Owner's Manual						
	W11635589	Quick Start Guide		W11352197	Flame Spreader (Left Rear)			FOLLOWING PARTS NOT ILLUSTRATED
2		Cooktop		W11352193	Flame Spreader (Right Front and Right Rear)	W11632719		Harness (Switch), Main
	W11585229	Stainless				W10878749		Harness, Spark Module
3		Burner Cap Kit					3400015	Screw, Grounding
	W11596821	Black (Set of 5)	9		Grommet		W10392003	Cord, Power
4		Grate Kit (Includes 3 Grates)		W11573785	Stainless		W10132200	Relief, Strain
	W11591619	Black (Set of 3)	10	W10758282	Screw		313438	Clip, Harness
5	W10827923	Electrode, Spring	11	W10723360	Orifice (Left Front)		W11573776	LP Conversion Kit
6		Knobs, Cooktop		W11364991	Orifice (Left Rear)		3801F935-51	Bracket, Tie Down
	W11573784	Stainless		W11610057	Orifice (Center)		7101P062-60	Screw (For Tie Down Bracket)
7	W11567145	Holder, Orifice (12K) (Left Front)		W11631338	Orifice (Right Front and Right Rear)			
	W11567151	Holder, Orifice (5K) (Left Rear)	12	W11640975	Wiring, Electrode (440MM)			
	W11567144	Holder, Orifice (18K) (Center)		W11642338	Wiring, Electrode (636MM)			
	W11567146	Holder, Orifice (9.1K) (Right Front and Right Rear)	13	W10826075	Rear, Hinge-Grate			

# BURNER BOX, GAS VALVES AND SWITCH PARTS



# BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	7	W10449143	Regulator, Pressure	15	W11574882	Tube, Gas (Right Rear)
2	W11576642	Manifold Assembly	8	W11566469	Bracket, Orifice Holder	16	7101P426-60	Screw
3	W11629615	Valve, Single (Left Front and Center)	9	W11350452	Spark Module	17	W10443110	Screw
	W11629616	Valve, Single (Left Rear)	10		Box, Burner (Not Serviced)	18	3196537	Screw
	W11629617	Valve, Single (Right Front and Right Rear)	11	W11574880	Tube, Gas (Left Front)	19	8286921	Screw, Burner Rail (M4)
4	8287055	Bracket, Single Valve	12	W11574881	Tube, Gas (Left Rear)	20	W11704153	Bracket, Orifice Holder Center Burner
5	W11507167	Seal, Switch Shaft	13	W11573983	Tube, Gas (Center)			
6	W11620860	Panel, Front	14	W11574883	Tube, Gas (Right Front)			