




GAS COOKTOP

MODELS:

WCGK7536PS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11352193	Flame Spreader (Left Front and Center)	14	W10598131	Foot Pad, Grate (Outer)
	W11613935	Owner's Manual		W11352197	Flame Spreader (Left Rear)	15	W11670654	Griddle
	W11635589	Quick Start Guide		W11352195	Flame Spreader (Right Front and Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
2		Cooktop				W11632719		Harness (Switch), Main
	W11573787	Stainless	9		Bezel	W10878749		Harness, Spark Module
3		Burner Cap Kit		W11573785	Stainless	3400015		Screw, Grounding
	W11596821	Black (Set of 5)	10	W10758282	Screw	W10392003		Cord, Power
4		Grate Kit (Includes 3 Grates)	11	W10723360	Orifice (Left Front)	W10132200		Relief, Strain
	W11591618	Black (Set of 3)		W11364991	Orifice (Left Rear)	313438		Clip, Harness
5	W10827923	Electrode, Spring		W11610057	Orifice (Center)	W11573776		LP Conversion Kit
6		Knobs, Cooktop		W11631338	Orifice (Right Front and Right Rear)	3801F935-51		Bracket, Tie Down
	W11573784	Stainless	12	W11640975	Wiring, Electrode (440MM)	7101P062-60		Screw (For Tie Down Bracket)
7	W11567145	Holder, Orifice (12K) (Left Front)		W11642338	Wiring, Electrode (636MM)			
	W11567151	Holder, Orifice (5K) (Left Rear)	13	W10826075	Rear, Hinge-Grate (Stainless Model Only)			
	W11567144	Holder, Orifice (18K) (Center)						
	W11567146	Holder, Orifice (9.1K) (Right Front and Right Rear)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	7	W10449143	Regulator, Pressure	15	7101P426-60	Screw
2	W11576641	Manifold Assembly	8	W11566469	Bracket, Orifice Holder	16	W10443110	Screw
3	W11629615	Valve, Single (Left Front and Center)	9	W11350452	Spark Module	17	3196537	Screw
	W11629616	Valve, Single (Left Rear)	10		Box, Burner (Not Serviced)	18	8286921	Screw, Burner Rail (M4)
	W11629617	Valve, Single (Right Front and Right Rear)	11	W11573975	Tube, Gas (Left Front)	19	W11573983	Tube, Gas (Center)
4	8287055	Bracket, Single Valve	12	W11573977	Tube, Gas (Left Rear)	20	W11704153	Bracket, Orifice Holder Center Burner
5	W11507167	Seal, Switch Shaft	13	W11573979	Tube, Gas (Right Front)			
6	W11620861	Panel, Front	14	W11573978	Tube, Gas (Right Rear)			