




## Dishwasher

### MODELS:

WDPS5118PB0 (Black)  
WDPS5118PW0 (White)  
WDPS5118PM0 (Stainless)


# CONTROL PANEL AND OUTER DOOR PARTS



# CONTROL PANEL AND OUTER DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Pocket	9		Button	10		Console Overlay
	W11230092	Black		W11230109	Cycles (Black)		W11230124	Left Hand (Black)
	W11230182	White		W11230184	Cycles (White)		W11230127	Right Hand (Black)
	W11230171	Stainless		W11230173	Cycles (Stainless)		W11230189	Left Hand (White)
2	W11230093	Cover, Control Board		W11230110	Options (Black)		W11230190	Right Hand (White)
3	W11230094	Cover, Control Board		W11230186	Options (White)			
4	W11230098	Control Board Assembly, Display		W11230174	Options (Stainless)	11		Panel, Front
5	W11230101	Light Guide, Double		W11230111	Delay (Black)		W11230128	Black
6	W11230104	Light Guide, Single		W11230187	Delay (White)		W11230191	White
7	W11230106	Light Guide, Triple		W11230179	Delay (Stainless)		W11230181	Stainless
8		Console Assembly		W11230113	Start (Black)	12	W11689791	Spring
	W11230107	Black		W11230188	Start (White)			
	W11230183	White		W11230180	Start (Stainless)			
	W11230172	Stainless						


# INNER DOOR PARTS



# INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11225863	Gasket, Vent	7	W11689794	Hook, Door Latch	11	W11689795	Dispenser
2	W11723970	Vent Assembly	8	W11230130	Inner Door Assembly	12	W11689796	Stiffener, Door
3	W11226131	Gasket	9	W11226223	Snap Ring	13	W11334683	Wiring Harness
4	W11226138	Deflector	10		Hinge Assembly			
5	W11230138	Base, Door Latch		W11226198	Left Hand			
6	W11226261	Gasket		W11226199	Right Hand			


# FILL DRAIN AND BASE PARTS



# FILL DRAIN AND BASE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11230142	Cover, Base	13		Access Panel	23	W11230153	Electronic Control
2	W11226333	Tub Support		W11230155	Black	24	W11226535	Cover, PCB Box
3	W11226329	Connecting Block, Tub		W11230192	White	25	W11226514	Block
4	W11230143	Base Assembly	14	W11689829	Drain Hose	26	W11226520	PCB Box
5	W11226335	Leveling Leg	15	W11226858	Float	27	W11689828	Inlet Valve
6	W11226568	Nut, Air Breather	16	W11230158	Pipe, Pressure Switch	28	W11230152	Bracket
7	W11226570	Gasket	17	W11689827	Pressure Switch	29	W11352633	Toe Panel, Bent (Black)
8	W11226325	Air Breather	18	W11226494	Seat, Float			
9	W11226867	Adjustment Screw, Door Spring	19	W11226339	Assembly, Pump Support		W11352630	Toe Panel, Bent (White)
10	W11230160	Spring, Door	20	W11226864	Microswitch			
11	W11230159	Door Rope	21	W11226540	Cover, Junction Box			
12	W11230154	Acoustic Panel	22	W11226537	Base, Junction Box			

# TUB AND FRAME PARTS






# TUB AND FRAME PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Tub Assembly (Not Serviced)	5	W11226280	Wheel	8	W11230139	Heating Element Assembly
2	W11226273	Stop, Track	6		Bracket	9	W11689825	Gasket, Tub
3		Track Assembly		W11226292	Left Hand	10	W11689797	Door Switch Assembly
	W11226276	Left Hand		W11226293	Right Hand			
	W11226277	Right Hand	7		Connecting Panel			
4	W11226286	Supporting Holder, Basket Guider		W11226289	Left Hand			
				W11226291	Right Hand			


# PUMP AND MOTOR PARTS



# PUMP AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11226875	Filter Handle	7	W11226887	Gasket, Pump	13	W11689831	Thermistor
2	W11226876	Filter	8	W11226889	Housing, Upper Pump	14	W11226898	Trubidity Sensor
3	W11226878	Sump	9	W11226891	Clamp	15	W11226877	Pump
4	W11230164	Motor	10	W11226893	Hose	16	W11226899	Sealing Gasket
5	W11226885	Housing, Lower Pump	11	W11226894	Inlet Hose	17	W11226900	Inlet Hose
6	W11226886	Impeller	12	W11689830	Drain Hose	18	W11226890	Clamp


# WASH SYSTEM PARTS



# WASH SYSTEM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11226868	Feed Tube Assembly	3	W11226870	Extension, Lower Sprayarm	4	W11230162	Lower Sprayarm
2	W11230161	Upper Sprayarm Assembly				5	W11230163	Filter Screen

# DISHRACK PARTS



# DISHRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11230167	Upper Rack Assembly	3	W11230169	Silverware Basket
2	W11689835	Lower Rack Assembly	4	W11230170	Miscellaneous Parts Bag