



## **24" BUILT-IN ELECTRIC SINGLE OVEN WITH CONVECTION**


### **MODELS:**

WOS52ES4MW00 (White)

WOS52ES4MB00 (Black)

WOS52ES4MZ00 (Stainless)

# OVEN PARTS




# OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11508921	Installation Instructions
	W11508845	Use and Care Guide
	W11568131	Tech Sheet
2	W11347847	Latch, Door
3	W11509867	Cap
4	W11594218	Washer, Teflon
5	W10549523	Filter, Line Noise

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10578780	Bumper
7	W10519818	Kit, Oven Screws
8	W11581007	Hinge, Running Mechanism
9	W10518387	Gasket, Door
10	W11348087	Lamp, Halogen 25 Watt (with Gasket)
11	W10517979	Trim, Lower
12	W10545973	Foot, Level Oven

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13		Liner, Oven (Not Serviceable)
		FOLLOWING PARTS NOT ILLUSTRATED
	W11594182	Harness, Main
	W11348047	Kit, Power Cord (No Plug)


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Control Panel	6	W11348033	Wiring, Side Control	11	W10519009	Gasket, Blower Motor
	W11594203	White	7		Trim, Vent	12	W11594206	Board, Power
	W11594176	Black		W10914742	White			
2	W11348035	Harness, Touch Display		W11594195	Black			
3	W11348132	Cover, Control	8	W11348046	Harness, Display to Power Unit			
4	W11348036	Wiring, Right Control	9	W11347859	Blower, Cooling Fan			
5	W11594177	PCBA, User Interface	10	W10490220	Thermostat, 165 Celcius (with Bracket)			


# OVEN DOOR PARTS



# OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10518369	Vent, Door Trim Top	7	W10831792	Spacer, Door Handle	11	W11509863	Support, Oven Glass
2	W10518307	Spacer, Door Trim Top	8		Handle, Door	12	W10518384	Support, Oven Door Glass
3	480121101609	Glass, Door Inner Assembly		W11594201	White	13		Assembly, Outer Door
4	W10518376	Glass, Door Inner		W11594197	Black		W11594202	White
5	W10519004	Spacer, Oven Door Glass	9	481010387617	Support, Oven Door Glass		W11594198	Black
6	W10410709	Washer, Door Handle	10	W11594161	Hinge, Door		W11594173	Stainless

# INTERNAL OVEN PARTS





# INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10762741	Grid, Oven Rack	5	W10901439	Nut, Fan	9	W11347861	Element, Upper Grill
2	W10519022	Screw, Grid	6	W10901438	Blade, Fan	10	W11348032	Element, Lower
3	W11594175	Baffle, Convection Fan	7	W11347858	Motor, Convection Fan			
4	W11347860	Element, Convection	8	W10635612	Rack, Oven			