




15" Undercounter Wine Center

MODELS:

WUW35X15DS02 (Stainless)

WINE CENTER PARTS



WINE CENTER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	17	W10782263	Cover, Evaporator Fan	37	W10782267	Plate, Switch
	W10739679	Use & Care Guide	18	W11290655	Control Panel Assembly	38	W10782241	Axis, Door
	W10792627	Energy Guide				39	W11255595	Stop, Door
2		Cabinet (Not a Servicable Part)	19	W10782293	LED Light	40	W10782254	Fan Assembly, Condenser
3	W11290639	Drier Filter	20	W10782222	Cover, Sensor	41	W11104118	Screw
4	W10782176	Power Cord	21	W11296649	Sensor (White Connector)	42	W11104122	Spring, Washer
5	W11290643	Water Tray	22	W10782255	Cover, Condenser Fan	43	W11104121	Washer
6	W11290645	Compressor	23	W11243800	Cover, Condenser			FOLLOWING PARTS NOT ILLUSTRATED
7	W11290646	Cover, PCB	24	W10782289	Condenser		W10782275	Starter
8	W11290662	Foam	25	W11290656	Baseplate		W10782192	Pin, PCB
9	W11290648	Main PCB	26	W10782249	Leg		W10782277	Overload Relay
10	W10782193	Hinge, Upper Right	27	W11244017	Support, Front		W10266810	Aluminum Tape
	W10782260	Hinge, Upper Left	28	W10782256	Slide, Rail			REFRIGERANT CHARGE
11	W11243790	Hinge, Lower Right	29	W10782243	Switch			0.98oz. R600A
	W11243796	Hinge, Lower Left	30	W10782242	Support, Switch			
12	W11243799	Cover, Rear	31	W11290657	Sensor (Red Connector)			
13	W10782261	Screw	32	W11244018	Grille			
14	W10782280	Evaporator	33	W11244034	Rack Assembly			
15	W10792631	Fan Assembly, Evaporator	34	W10782294	Door Assembly			
16	W10782281	Evaporator Cover	35	W10782266	Handle			
			36	W10782286	Gasket, Door			