

AMANA®


ELECTRIC RANGE (Radiant Elements)

MODELS:

AER6303MFB6 (Black)

AER6303MFW6 (White)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	8273993	Element (1800W)	8	W11379945	Bracket, Anti-Tip
	W11509598	User Instructions			(Left Front and Right Rear)	9	7101P485-60	Screw, Anti-Tip Kit
	W11469631	Quick Start Guide		W10248261	Element (1200W)			FOLLOWING PARTS NOT ILLUSTRATED
	W11326823	Tech Sheet			(Right Front and Left Rear)		W11452627	Harness, Wire (Main)
2	W11600012	Spring, Element	6	3196169	Screw		W11171894	Harness, Cooktop (Left)
3	W10691223	Pan, Radiant Element	7	W10607641	Bracket, Cooktop (Left)		W11134551	Harness, Cooktop (Right)
4		Cooktop		W10607642	Bracket, Cooktop (Right)			
	W10853124	Black						
	W10853442	White						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	3148952	Switch, Infinite (Yellow)	7		Knobs
	W11130372	Black (Left)					W10844801	Black
	W11130371	White (Left)			(Right Front and Left Rear)		W10844800	White
	W11130379	Black (Right)				8	W10134247	Shield, Heat
	W11130378	White (Right)		3148953	Switch, Infinite (Green)	9	3400882	Screw
2	W10525121	Bracket, Console Mounting			(Left Front and Right Rear)	10	8272473	Cover, Upper Rear
3		Panel, Console	5	W10695491	Bracket, Control	11		Control, Electronic (LCX)
	W11157017	Black	6	3196178	Screw		W11511568	Black
	W11157016	White					W11511570	White


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	15	W10390008	Base Rail Assembly (Left)	27	3196154	Screw
2	W10134285	Tube, Vent				28	W10910404	Counterweight
3		Panel, Side		W10390007	Base Rail Assembly (Right)	29	W11034869	Screw
	W10162245	Black				30	W10674705	Glide, Drawer Front
	W10575396	White	16	W10058460	Foot, Leveling	31	3196560	Screw
4	3400029	Nut	17	3196548	Fuse, Thermal	32	W11510560	Barrier Rail, Rubber (Left and Right)
5	W10129032	Seal, Door	18	3196172	Screw	33	W11464547	Bracket, Front Frame
6	9757340	Element, Broil	19	W10404688	Clip, Oven Support			
7	W11111743	Element, Bake	20	3186034	Bracket, Service			
8	W10326122	Cover, Terminal Block	21	W10245259	Block, Terminal			FOLLOWING PARTS NOT ILLUSTRATED
9	3196169	Screw	22	3400080	Screw	W10333344		Insulation, Flue
10	W11173792	Rack, Oven	23	W10181986	Sensor, Oven	8273263		Insulation, Wrap
11	W10341186	Front Foot Assembly	24	W11634772	Light Assembly	8272611		Insulation, Back
12	W10031780	Screw	25	W10571723	Bulb, Halogen 40 Watts			
13	8054068	Retainer, Insulation	26	W10281322	Kit, Bare Wire Adapter Block			
14	W10137382	Clip, Panel						

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top
	W10310922	Black
	W10310920	White
2	W10168559	Screw
3		Handle, Door
	W10323589	Black
	W10323588	White
4	9761344	Liner, Door
5	W10031790	Screw
6	W11367326	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W11380221	Retainer, Insulation
8	W10299225	Hinge, Active
9		Glass, Outer
	W11687921	Black
	W10851723	White
10		Trim, Side
	W10746436	Black (Left)
	8523172	White (Left)
	W10746435	Black (Right)
	8523166	White (Right)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10327235	Screw
12		Trim, Lower
	W11444043	Black
	W11444042	White
13	W11379944	Strap, Door
14	W10200660	Screw
15		Badge
	W10846751	Black
	W10849465	White
16	W10299227	Hinge, Door (Passive)

DRAWER AND BROILER PARTS



DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	4		Rivet, Push	5	W10674708	Glide, Drawer Rear
	W11123900	Black		3196813	Black	6	3196165	Screw
	W11123901	White		3196814	Rivet, Plastic (WHITE)			
2	W10688022	Drawer, Storage						
3	W10462912	Bracket, Mounting Drawer						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	8212473	Universal Silver
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	3191048	Glass Cleaner
	4396923	Broiler Pan and Grid