




**ELECTRIC RANGE  
(Fingerprint Resistant)**

**MODELS:**

MFES8030RZ0 (Stainless Steel)


# COOKTOP PARTS



# COOKTOP PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                               | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>   | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                 |
|-------------------|-----------------|--|-------------------|-----------------|----------------------|-------------------|-----------------|------------------------------------|
| 1                 |                 | Literature Parts                                 | 7                 | W11640572       | Pan, Radiant Element | 14                | W11117008       | Element (3200W)                    |
|                   | W11638635       | Owners Manual                                    | 8                 | W11379945       | Bracket, Anti-Tip    |                   |                 | (Right Front)                      |
|                   | W11638796       | Quick Start Guide                                | 9                 | 7101P485-60     | Screw, Anti-Tip Kit  |                   |                 | FOLLOWING PARTS<br>NOT ILLUSTRATED |
|                   | W11639167       | Tech Sheet                                       | 10                | W11668631       | Element, Warm Zone   | W11448070         |                 | Harness, Main                      |
| 2                 | W11600012       | Spring, Element                                  |                   |                 | (Center)             | W11448104         |                 | Harness, Warm Zone                 |
| 3                 | W11593284       | Bracket, Cooktop                                 | 11                | 8273994         | Element (1200W)      | W11334489         |                 | Harness, Cooktop                   |
| 4                 | W11616645       | Cooktop (Includes,<br>Cooktop Bracket)           |                   |                 | (Right Rear)         | 3196520           |                 | Clip, Wire                         |
| 5                 | W10248259       | Element, Bridge<br>(Left Front and Left<br>Rear) | 12                |                 | Bullnose             | W11585874         |                 | Harness, Hidden Bake               |
|                   |                 |  |                   | W11624928       | Stainless            |                   |                 |                                    |
| 6                 | 3196169         | Screw  | 13                | 3400080         | Screw                |                   |                 |                                    |


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>  | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-------------------|-----------------|-------------------------------|-------------------|-----------------|---------------------|-------------------|-----------------|--------------------------------|
| 1                 |                 | Endcap                        | 5                 | 3196178         | Screw               | 13                | W10578768       | Switch, Infinite (Right Rear)  |
|                   | W11625424       | Stainless (Left)              | 6                 | W11371599       | Bracket, Control    |                   |                 |                                |
|                   | W11625421       | Stainless (Right)             | 7                 |                 | Knob                |                   | W11637795       | Switch, Infinite (Right Front) |
| 2                 |                 | Control, Electronic (LCX)     |                   | W11436130       | Stainless           | 14                | 3196169         | Screw                          |
|                   | W11436172       | Black                         | 8                 | W11363806       | Shield, Heat        | 15                | W11394231       | Cover, Rear Flue               |
| 3                 |                 | Panel, Console                | 9                 | 3400882         | Screw               | 16                | 3196068         | Lens, Indicator                |
|                   | W11730183       | Stainless                     | 10                | W11392241       | Cover, Upper Rear   |                   |                 |                                |
| 4                 | W10437092       | Switch, Infinite (Left Front) | 11                |                 | Lower Panel         |                   |                 |                                |
|                   | W10843843       | Switch, Infinite (Left Rear)  |                   | W11625404       | Stainless           |                   |                 |                                |
|                   |                 |                               | 12                | W11643797       | Gasket, Lower Panel |                   |                 |                                |


# CHASSIS PARTS



# CHASSIS PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>         | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>                    |
|-------------------|-----------------|----------------------------|-------------------|-----------------|---------------------------|-------------------|-----------------|---------------------------------------|
| 1                 | W10289077       | Receiver, Hinge            | 21                | W11591244       | Block, Terminal           | 42                | W11635909       | Fan, Convection                       |
| 2                 | W10362924       | Screw                      | 22                | 3400968         | Nut                       | 43                | W11411632       | Blower, Tube                          |
| 3                 |                 | Panel, Side                | 23                | 3196178         | Screw                     | 44                | W11642475       | Tube, Clamp                           |
|                   | W11445467       | Black                      | 24                | W11634772       | Light Assembly            | 45                | W11510560       | Barrier Rail, Rubber (Left and Right) |
| 4                 | 3400029         | Nut                        | 25                | W10571723       | Bulb, Halogen 40 Watts    | 46                | W10516115       | Screw                                 |
| 5                 | W11491751       | Seal, Door                 | 26                | 3400016         | Screw                     | 47                | W11373155       | Cover, Conv Fan                       |
| 6                 | W10308476       | Element, Broil             | 27                | W11633068       | Sensor                    | 48                | W10183712       | Tray, Hidden Bake                     |
| 7                 | 9755770         | Element, Bake              | 28                | 3196169         | Screw                     | 49                | W10134125       | Shield, Heat                          |
| 8                 | 3196174         | Screw                      | 29                | W11365827       | Terminal Block, Cover     | 50                | W10646923       | Card, Insulator                       |
| 9                 | W11621245       | Tube, Vent                 | 30                | W10031780       | Screw                     | 51                | W10281322       | Kit, Bare Wire Adapter Block          |
| 10                | W10674705       | Glide, Drawer Front        | 31                | 9757239         | Rod, Door Switch          | 52                | W11633903       | Exhaust, Vent                         |
| 11                | W10341186       | Front Foot Assembly        | 32                | W11034869       | Screw                     | 53                | W11596201       | Corner, Cover                         |
| 12                | W10067840       | Screw                      | 33                | W10910404       | Counterweight             | 54                | W11367541       | Side, Fan Cover                       |
| 13                | W10134121       | Tray, Insulation           | 34                | W11511828       | Switch, Door              | 55                | 3400701         | Screw                                 |
| 14                | W10137382       | Clip, Panel                | 35                | W11464547       | Bracket, Front Frame      |                   |                 | FOLLOWING PARTS NOT ILLUSTRATED       |
| 15                | W10390008       | Base Rail Assembly (Left)  | 36                | W11092984       | Screen, Vent              |                   |                 |                                       |
|                   | W10390007       | Base Rail Assembly (Right) | 37                | 9761013         | Front Door Latch Assembly | W10774939         |                 | Insulation, Wrap                      |
| 16                | W10058460       | Foot, Leveling             | 38                | 3196560         | Screw                     | W11407378         |                 | Insulation, Back                      |
| 17                | 3196548         | Fuse, Thermal              | 39                | W10078380       | Rod, Latch                | W11404469         |                 | Insulation, Flue                      |
| 18                | 3196172         | Screw                      | 40                | W10107820       | Rear Door Latch Assembly  |                   |                 |                                       |
| 19                | W10404688       | Clip, Oven Support         | 41                | W11173792       | Rack, Oven                |                   |                 |                                       |
| 20                | W11673744       | Bracket, Service           |                   |                 |                           |                   |                 |                                       |

# DOOR PARTS






# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|----------------------|
| 1                           |                 | Handle, Door         |
|                             | W11495825       | Stainless            |
| 2                           | W10316950       | Frame, Glass         |
| 3                           | W10388635       | Hinge, Door (Active) |
| 4                           | 9761344         | Liner, Door          |
| 5                           | W10031790       | Screw                |
| 6                           | 9758162         | Glass, Inner         |
| 7                           | W11380222       | Retainer, Insulation |
| 8                           | W10440013       | Hinge, Door (Active) |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            |
|-----------------------------|-----------------|-------------------------------|
| 9                           |                 | Glass Assembly, Outer Door    |
|                             | W11631954       | Stainless (Includes Badge)    |
| 10                          | W11157607       | Bracket, Handle Mount (Right) |
|                             | W11417442       | Bracket, Handle Mount (Left)  |
| 11                          | W10327235       | Screw                         |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     |
|-----------------------------|-----------------|------------------------|
| 12                          | 3196154         | Screw                  |
| 13                          | W10031780       | Screw                  |
| 14                          | W10278991       | Insulation, Door Strip |
| 15                          | W10200660       | Screw                  |
| 16                          | W11628148       | Badge                  |

# DRAWER PARTS



# DRAWER PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 1                           | 3196169         | Screw              |
| 2                           | W10688022       | Drawer, Storage    |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          |
|-----------------------------|-----------------|-----------------------------|
| 3                           | W10462910       | Bracket, Mounting<br>Drawer |
| 4                           | W10674708       | Glide, Drawer Rear          |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>  |
|-----------------------------|-----------------|---------------------|
| 5                           |                 | Panel, Drawer Front |
|                             | W11449698       | Stainless           |

# OPTIONAL PARTS

## REFINISHING MATERIAL

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>        |
|-------------------|-----------------|---------------------------|
|                   | 242756          | Oven Liner Touch Up Paint |

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-------------------|-----------------|-------------------------|
|                   | 72017           | White                   |
|                   | 511873          | White Porcelain (2 oz.) |

## PAINT, BULK (1 QT.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|--------------------|
|                   | 799344          | White (Uncut)      |

## INSULATION

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>               |
|-------------------|-----------------|----------------------------------|
|                   | 261514          | Insulation (1-1/2 x 24 x 120 in) |
|                   | 240132          | Insulation (2-1/2 x 22 x 120 in) |

## PAINT, PRESSURIZED SPRAY (12 OZ.)

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u> |
|-------------------|-----------------|--------------------|
|                   | 350930          | White              |
|                   | 285006          | Black              |
|                   | 206922          | Primer (White)     |

## ACCESSORY PARTS

| <u>Illus. No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-------------------|-----------------|--------------------------------|
|                   | W10355051       | Cleaner, Cooktop               |
|                   | WA906B          | Scraper, Cooktop               |
|                   | W11601635       | Griddle                        |
|                   | 4396923         | Broiler Pan and Grid           |
|                   | W10123240       | Rack, Broiler Pan and Roasting |