




GAS RANGE
Finger Print Resistant

MODELS:

WFG775H0HZ6 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Grate Kit (Includes 2 Grates)	17	W10879790	Grate Hinge Spacer
	W11427474	Quick Start Guide				18	3196184	Screw
	W11448510	Use and Care Guide		W10865170	Black			FOLLOWING PARTS NOT ILLUSTRATED
	W11565452	Tech Sheet	9	W10673618	Screw			
2		Kit, Burner Cap (Set of 4)	10	W11379946	Manifold Panel Bracket		W11458869	Harness, Main
	W11498499	Black (Set of 4)	11	W11379358	Rear Gas Cooktop Bracket		W10753750	Harness, Bake and Broil
3	W10067840	Screw	12	7101P485-60	Screw, Anti-Tip Kit		W10334923	Clip, Gas Wiring
4	W11367107	Burner Kit	13	W11379945	Bracket, Anti-Tip		313438	Clip, Harness
5		Cooktop	14		Bezel		7111P017-60	Clamp, Wire
	W11418087	Black		W10917236	Stainless		3196896	Clip, Wire
6		Panel, Manifold	15	W11043399	Griddle		3196520	Clip, Wire
	W11025417	Stainless	16		Hinge, Grate			
7		Knob			(Not Serviced)			
	W10917221	Stainless						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6	W10192841	Shield, Heat	13	W10797001	Bracket, Ignitor
	W11213290	Black (Left)	7		Control, Electronic (LCX)	14	W10901802	Panel, Backer
	W11213292	Black (Right)		W11520692	Black	15		Bracket, Eye Brow
2	W10516123	Bracket, Console Mounting	8	W10762981	Bracket, Mounting		W11443964	Black
3		Console	9	W10184251	Cover, Back	16	3196169	Screw
	W10869988	Stainless	10	3196178	Screw	17	W10551614	Spreader, Clip-Spring
4	W10920631	Module, Spark DSI	11	W10856361	Bracket, Control			
5	W10198745	Cover, Upper	12	W11350452	Spark Module			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	16	W11040249	Assembly, Flue (Upper)	31	W10390008	Base Rail Assembly (Left)
2	9758701	Spacer, Door	17	W10362924	Screw		W10390007	Base Rail Assembly (Right)
3	W10273002	Bracket, Oven Support	18	W10323077	Diffuser, Flame	32	3196560	Screw
4		Panel, Side	19	3196178	Screw	33	W10389555	Fan, Convection
	W10162245	Black	20	W10531060	Rack, Oven	34	W10346154	Cover, Convection
5	W10158780	Cover, Rear Fan	21	W11491752	Gasket, Door	35	W10362924	Screw
6	W11511828	Switch, Door	22	W10031780	Screw	36	W10289145	Rack, Oven (Gull-Wing)
7	W10137382	Clip, Panel	23	W10273195	Shield, Heat	37	3196165	Screw
8	W10919715	Gasket	24	W10273192	Rod, Door Switch			FOLLOWING PARTS NOT ILLUSTRATED
9	W10289077	Receiver, Hinge	25	W10910642	Cord, Power		4820F015-59	Insulation, Strap
10	W10058460	Foot, Leveling	26	W10035900	Support, Oven Bottom		W10526208	Insulation, Wrap
11	W10211368	Bottom, Oven	27	W11379356	Pan, Bake		W10526209	Insulation, Main Back
12	W10586204	Sensor	28	W11634772	Light Assembly			
13	3601P356-45	Baffle, Bake Burner	29	W10571723	Bulb, Halogen 40 Watts			
14	3196178	Screw	30	W10341186	Front Foot Assembly			
15	W10435470	Brace, Main Back						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11352012	Valve, Gas (Left Front and Right Front)	19	3196385	Screw
2	W11459263	Orifice Holder Assembly (18K) (Left Front)		W11352013	Valve, Gas (Left Rear and Center)	20	3400016	Screw
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)		W11352015	Valve, Gas (Right Rear)	21	W11428858	Electrode (Right Front, Right Rear)
	W11459260	Orifice Holder Assembly (15K) (Right Front)	9	W10224921	Bracket, Aegis		W11428831	Electrode (Left Front, Left Rear, Center)
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	10	W10439242	Burner, Broiler	22	W10827923	Electrode, Spring FOLLOWING PARTS NOT ILLUSTRATED
	W11459261	Orifice Holder Assembly (8K) (Center)	11	W10680035	Burner, Bake		W11489399	LP 5 Orifice Conversion Kit
3	W10295996	Bracket, Saddle Valve	12	W10720102	Valve, Gas		W10566535	LP Conversion Kit (Bake and Broil)
4	W10510125	Tubing, Main Supply	13	W10324262	Igniter, Bake			
5	W10783317	Switch, 5 Burner Manifold Harness	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)			
6	3601P336-45	Baffle, Broil Burner	15	W10776437	Fitting, Broil			
7	W11418925	Manifold Assembly	16	W10333842	Electrode, Broil			
			17	W11485988	Orifice (18K) (Left Front)			
				W11485873	Orifice (9.5K) (Left Rear)			
				W11428753	Orifice (15K) (Right Front)			
				W11485871	Orifice (5K) (Right Rear)			
				W11485874	Orifice (8K) (Center)			
			18	3196178	Screw			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11379948	Glass Spacer	9		Glass Assembly, Outer Door	15	W10884775	Badge
2	W11091878	Screw				16	W10319024	Washer, Door
3		Handle, Door		W10864214	Stainless			
	W10918786	Stainless	10		Vent, Trim			
4	W10826568	Liner, Door		W10887939	Black			
5	W10031790	Screw	11	W10327235	Screw			
6	W11223202	Glass, Inner	12	W10813139	Rail, Vertical Support			
7	W10541911	Bracket, Glass Upper Handle	13	W10031780	Screw			
8	W10885519	Hinge, Door (Active)	14	W10813140	Rail, Horizontal Support			

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	4	W10441804	Slide, Drawer (Left)	6		Handle, Door
	W11449702	Stainless		W10441805	Slide, Drawer (Right)		W10918786	Stainless
2	3196169	Screw	5	W10318026	Bracket, Mounting	7	W10498399	Screw
3	W10688022	Drawer, Storage						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	285006	Black
	206922	Primer (White)
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORIES NOT INCLUDED OR ILLUSTRATED
	30-48KITRC	Gas Range Connector Kit
	W11123246	Griddle, Gas Range
	4396923	Broiler Pan and Grid
	4396096RB	Griddle