




GAS DRYER

MODELS:

WGD4720RW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	693995	Screw	9	8536939	Clip, Spring
	W11685647	Owners Manual	4	W11255768	Channel, Water	10		Console Assembly
	W11708031	Tech Sheet	5	12990702	Screw		W11706452	White
	W11708005	Quick Start Guide	6	W11480682	Bracket, Console	11	W11157863	Harness, Main Wiring
2		Top	7	W11719384	Harness, ACU to HMI	12	W10884773	Badge
	W10208383	White	8	W11709753	Assembly, Knob	13	9740848	Screw


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8317339	Cover, Terminal Block	14	W11307535	Assembly, Door Switch	30	W10121316	Clamp, Motor Mount
2	3390647	Screw	15	W11715541	Bracket, Hinge	31	W11404905	Bracket, Motor Mounting
3	W10773242	Screw	16	3387242	Seal, Front Panel	32	W10774832	Switch, Broken Belt
4	W10208382	Bracket, Rear	17	3357011	Screw	33	343641	Screw
5	W10487431	Panel, Rear	18		Plug, Front Panel	34	W11575710	Belt, Drive
6		Panel, Side (Left)		8564457	White	35	W11308561	Cord, Power
	W11177568	White	19	W10288126	Screw	36	489463	Screw
7		Panel, Side (Right)	20	W11126752	Strike, Door			DRYER EXHAUST KIT NOT INCLUDED
	W11177569	White	21		Panel, Front			
8	W11707353	Appliance Control Unit (ACU)		W11714853	White		W10323246	Kit, 4-Way Vent
9	693995	Screw	22	3978776	Bracket, Gas Pipe			
10	W10504381	Pad, Foam	23	W10547287	Assembly, Idler			
11	8529757	Bracket, Burner	24	W10468057	Assembly, Pulley			
12	8565046	Base, Cabinet	25	W10512946	Washer, Tri Ring			
13	3392100	Foot, Dryer	26	W10446781	Spring, Idler			
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	27	3389420	Screw			
			28	W11322192	Assembly, Motor			
			29	8066184	Pulley, Motor			


BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10293765	Assembly, Air Duct	13	W10211896	Assembly, Lint Duct	27	8573713	Cut-Off, Thermal
2	3390647	Screw	14	W10414388	Clip, Lint Duct	28	338906	Sensor, Radiant
3	W10001120	Nut, Hex (Left Hand Thread)	15	W11655534	Assembly, Collar (Includes Seal)	29	W10508188	Assembly, Drum (Complete)
4	3387459	Washer	16	697772	Wheel, Blower	30	W10521122	Seal, Drum Front
5	W10359271	Shaft, Drum Roller - Right Hand Thread	17	W10211911	Housing, Blower	31	W10416098	Baffle, Drum
6	W10512946	Washer, Tri Ring	18	693995	Screw	32	W10219342	Screw
7	W10314171	Roller, Support	19	W10693363	Fuse, Thermal (91C)	33	W10521118	Seal, Drum
8	W10359272	Shaft, Drum Roller - Left Hand Thread	20	8577274	Thermistor	34	W11162462	Bulkhead, Rear
9	W10673493	Bulkhead, Front	21	W10342188	Exhaust Pipe	35	W10672683	Assembly, Outlet Grill and Housing
10	W10516085	Lint Screen	22	W10344699	Collar, Duct	36	3387223	Sensor, Electrode
11	8529007	Plug, Rear Bulkhead	23	W10623852	Thermistor, Gas Inlet	37	W10298258	Harness, Sensor
12	W10211950	Seal, Housing Outlet	24	3934666	Nut, Hex	38	3387230	Screw

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Outer Door	6	W11050690	Bracket, Door Catch	11	W11607789	Cover, Hinge
	W11114013	White	7	W10208401	Assembly, Spring Catch	12	W11607784	Cover, Handle
2	W11606588	Assembly, Inner Door	8	W10288126	Screw	13	9742177	Screw
3	W11100789	Bracket, Glass	9	W11114011	Hinge Assembly			
4	W10891207	Glass, Door	10	8540479	Screw, Grounding			
5	W11183899	Seal, Glass						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564941	Burner Assembly 60 Hz.	8	3387057	Screw	15	3387561	Clamp, Pipe
2	688617	Tube, Burner	9	3389871	Base, Burner	16	3389889	Bracket, Support
3	694298	Bracket, Ignitor	10		Orifice, Burner			FOLLOWING PARTS NOT ILLUSTRATED
4	686590	Ignitor		15418	Type 1 (Natural)			
5	W10366705	Screw	11	326049536	Screw	W11581317		Kit, LP Gas Dryer Conversion
6	343641	Screw	12	W10328463	Coil (60 Hz)			
7	W11564944	Valve, Gas 60 Hz. (Complete)	13	W10295523	Pipe Plug			
			14	3390647	Screw			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		PAINT, TOUCH-UP (1/2oz.)
	72017	White
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	350938	Gray Primer
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	8522199	Kit, Dryer Vent Testing
	80047	Kit, Dryer Repair
	W10315283	Kit, Door Reversing
	W10869845	Kit, Stack
		ACCESSORY PEDESTALS
		XHP1000XW White 10" Pedestal
		WFP2715HW White 15.5" Pedestal