



GAS RANGE


MODELS:

WGG745S0FE10 (Black Ice)

WGG745S0FH10 (White Ice)

WGG745S0FS10 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Set, Grate	16		Hinge, Grate (Not Serviced)
	W11426601	Owner's Manual		W11241665	Black			
	W11430268	Quick Start Guide	9		Panel, Manifold	17	W10465081	Grate, Bumper
	W11565449	Tech Sheet		W10828392	Black	18	3368921	Screw
2		Kit, Burner Cap		W10828396	White	19	7101P376-60	Screw
	W10299236	Black		W10823297	Stainless	20	4449154	Screw
3		Cooktop (Includes Hinges)	10	W10333445	Base, Burner (Fish Burner Only)			FOLLOWING PARTS NOT ILLUSTRATED
	W10785917	Black	11		Kit, Burner Cap (Fish Burner Only)		W11448060	Harness, Main
	W10785916	White		W10171140	Black		W11172428	Harness, EOL (DOFSR)
4	W10406878	Head, Burner (17.5K) (Left Front)	12		Endcap, Manifold		7101P027-60	Screw, Ground
	W10406243	Head, Burner (6K) (Left Rear and Right Rear)		W10719582	Black (Left)		W10408058	Harness, Spark
	W10406797	Head, Burner (12.5K) (Right Front)		W10719581	Black (Right)		W11172531	Harness, Sensor & Locks
	W10336094	Head, Burner (Center)		W10719580	White (Left)		7111P017-60	Clamp, Wire
5		Knob, Control		W10719579	White (Right)		8019P026-60	Clip, Wire-Wrap Nylon
	W10850036	Stainless		W10823301	Stainless (Left)		7109P036-60	Washer
6	W10518258	Bracket, Cooktop Support	13	3196160	Screw			
7	8016P022-60	Glide, Main Top	14	W10850043	Bezel			
			15	7101P633-60	Screw (Black)			
				7101P636-60	Screw (White)			
				7101P634-60	Screw (Stainless Model)			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Support, Backguard	5	W11541201	Control, Maxwell	11	W10906658	Screw
	W10319109	Black (Left)	6		Assembly, Membrane (Including Bracket)			(Stainless Models Only)
	W10319111	Black (Right)		W10826681	Black			
	W10319110	White (Left)		W10826682	White			
	W10319112	White (Right)		W10840440	Stainless			
2	7101P338-60	Screw	7	W10278697	Shield, Vent			
3		Console	8	7101P434-60	Screw			
	W10318551	Black	9	W10776098	Cover, Backguard			
	W10318552	White	10	W10309232	Insulation, Wire Cover			
	W10318550	Stainless						
4	7101P633-60	Screw (Black)						
	7101P636-60	Screw (White)						


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10319002	Tubing, Broil	8	W10718180	Valve (17K)	25	7101P653-60	Screw
2	W10643268	Holder, Orifice (17K)			(Left Front and Right Front)	26	W10642388	Tubing (Supply Shutoff To Manifold)
		(Left Front)				27	W10272520	Bracket, Orifice
	W10643269	Holder, Orifice (5K)		W10718182	Valve (5K)	28	W10319059	Bracket, Spark Module
		(Left Rear)			(Left Rear and Right Rear)	29	W10949105	Bracket, Saddle Valve
	W10643270	Holder, Orifice (10K)		W10718181	Valve (10K)	30	4449154	Screw
		(Right Front)			(Center)	31	W10324366	Holder, Electrode Extension
	W10643271	Holder, Orifice (5K)	9	7103P030-60	Nut, Wing	32	W10636384	Extension, Electrode
		(Right Rear)	10	W11191260	Burner, Broiler	33	7431P053-60	Module, Spark
	W10643272	Holder, Orifice (7K)	11	W11105585	Burner, Bake	34	7101P434-60	Screw
		(Center)	12	W10342662	Orifice, Bake	35	7101P502-60	Screw
3	W10639161	Orifice		W10342661	Orifice, Bake	36	W10565365	Electrode, Spark
		(Left Front)			(Lower)			(Left Front, Left Rear, Right Front, Right Rear)
	W10407673	Orifice	13	7432P143-60	Ignitor, Bake		W10637673	Electrode, Fish
		(Left Rear and Right Rear)	14	W10298865	Shield, Bake			(Center)
	W10407675	Orifice	15	W10292293	Fitting, Broiler	37	W10276466	Bracket, Manifold
		(Right Front)	16	4005F421-45	Cover, Ignitor Wire			(Bottom)
	W10324014	Orifice	17	7103P195-60	Nut, Mounting	38	7101P282-60	Screw
		(Center)	18	7101P426-60	Screw	39	W10368614	Valve, Shut Off
4	W10546238	Valve/Regulator	19	W10295997	Screw, Valve			FOLLOWING PARTS NOT ILLUSTRATED
5	W10664240	Harness, Switch	20	W10272528	Baffle, Bake		W10591270	Kit, LP Conversion
6	W10324738	Ignitor, Gas	21	7101P624-60	Screw		W10324646	Insulation, Orifice
7	W10806878	Assembly, Manifold	22	3601F358-45	Baffle, Broil Burner			
			23	8273062	Screw			
			24	W10524331	Tubing (Supply Regulator to Shutoff)			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10319038	Shield, Gemini	16	W10321446	Assembly, Outlet Flue (Upper)	29	311255	Bulb, Oven Light
2	W11479123	Spacer, Side Panel		W10321445	Assembly, Outlet Flue (Lower)	30	8285593	Cover, Connector
3	W10267456	Screw, Shoulder				31	W10777398	Bottom, Oven Drip
4		Assembly, Side Panel	17	4449040	Screw	32	12992902	Screw
	W11532477	Black	18	W10319087	Bracket, U Channel	33	W10626077	Cover, Inner Main Back
	W11532469	White	19	7101P485-60	Screw, Anti-Tip Kit	34	W10626078	Cover, Outer Main Back
5	3801F656-51	Bracket, Anti-Tip	20	W10324643	Support, Insulation	35	W11509400	Base, Chassis INSULATION
6	W10319000	Gasket, Gemini Oven Shield	21	W11544370	Light Assembly		W10344586	Insulation, Floor
7	W10863342	Support, Lower Oven	22	W10683517	Lock, Rear Mount		W10318910	Insulation, Wrapper (Upper)
8	7101P507-60	Foot, Leveler	23	W10538516	Shield, Side Insulation		W10318918	Insulation, Back (Upper)
9	W10105790	Bumper & Screw	24	W10357697	Bracket, Side Panel		W10318911	Insulation, Wrapper (Lower)
10	7430P044-60	Sensor, Oven	25	W11507143	Gasket, Oven Door (Upper)		W10204081	Insulation, Back (Lower)
11	W10268558	Cover, Lower Wire		W11491753	Gasket, Oven Door (Lower)			
12	4449743	Screw	26	7101P426-60	Screw			
13	W10261387	Cover, Main Wire	27	W10410463	Cover, Hinge (Left)			
14	W11040249	Assembly, Flue (Upper)		W10410461	Cover, Hinge (Right)			
	W10272519	Assembly, Flue (Lower)	28	W10272546	Bottom, Oven			
15	W10668728	Back, Main						


UPPER DOOR PARTS



UPPER DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11051040	Lining, Door	9	W10485733	Hinge, Door (Left)	14	W10284411	Screw with Washer
2	W11099272	Glass, Inner		W10485732	Hinge, Door (Right)	15	W10317886	Screw
3	W10272708	Frame, Glass	10		Standoff, Handle	16	W10477496	Screw
4	W10292297	Screw		W10410341	Black			
5	W10485723	Retainer, Insulation		W10429492	White			
6	W10321271	Insulation, Door	11		Handle, Door			
7	W10289077	Receiver, Hinge		W10254687	Stainless			
8		Assembly, Door	12		Assembly, Door			
	W10675404	Black Ice		W10845039	Stainless			
	W10675403	White Ice	13	W10031780	Screw			


LOWER DOOR PARTS



LOWER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door	4	W10426267	Screw	11	W10340464	Retainer, Insulation
	W10254687	Stainless	5	W10272594	Frame, Glass	12	W10321285	Insulation, Door
2		Assembly, Door	6		Standoff, Handle	13	W10272329	Receiver (Left)
	W11528029	Black Ice		W10410341	Black		W10272328	Receiver (Right)
	W11528053	White Ice		W10429492	White	14	W10884775	Badge
3	W10294695	Bracket, Handle	7	9757706	Glass, Inner	15		Assembly, Door
		(Black Ice & White Ice Models Only)	8	W10335434	Hinge, Door (Left)		W11528034	Stainless
	W10575689	Bracket, Handle		W10335433	Hinge, Door (Right)	16	7109P084-60	Washer, Fiber
		(Stainless Models Only)	9	W10272698	Lining, Door	17	W10898280	Screw
			10	W10292297	Screw	18	W10284411	Screw with Washer

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10179152	Rack, Oven	5	W10274268	Insulation, Convection Motor	8	4448988	Cover, Fan
2	W10631506	Motor, Convection	6	W10339476	Plate, Insulation	9	W10249980	Element, Convection (120 VAC)
3	W10631503	Blade, Fan	7	4449154	Screw	10	W10720084	Screw
4	W10631504	Nut, Acorn (LH)						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		Paint, Touch-Up 1/2 Oz.
	72032	Black
	72017	White
		Paint, Spray (12-oz.)
	285006	Black
	350930	White
	350938	Gray Primer
	350942	White Primer
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORIES
	W11042467	Spray, Stainless Steel Cleaning
	W11042470	Cooktop Cleaning Kit