


KitchenAid®

15" ELECTRIC CERAN 2 BURNER COOKTOP

MODELS:

KECC056RBL06 (Black)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	3192439	Seal, Limiter	19	8273994	Element (1200W)
	8286066	Instructions, Installation	9	3193012	Light, Indicator			(Front)
	3192609	Wiring Diagram	10		Knob, Control		8273993	Element (1800W)
	W10162162	Use & Care Guide		9750372FF	Black			(Rear)
	8304571	Instructions, Undercounter	11	8286988	Box, Burner	20	4455364	Bracket, Support
2		Cooktop, Glass	12	4455917	Bracket, Cooktop Mounting	21	7101P426-60	Screw
	W10566742	Black	13	3400093	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	246119	Screw	14	3196537	Screw		W11171891	Harness, Cooktop
4	W10414006	Bracket, Mounting	15		Grommet		W11190493	Assembly, Conduit
5	3183956	Seal, Switch Cover		8285469	Black		98997	Clip
6	9759094	Spring, Locator	16	7101P309-60	Screw		3400015	Screw, Grounding
7	3191049	Switch, Infinite (Front)	17	3192721	Rail, Element Support		8286642	Tape, Foam
	3191050	Switch, Infinite (Rear)	18	3192612	Lamp, Hot Surface Indicator			

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	31464	Cleaner, Cooktop
	WA906B	Scraper, Cooktop
	8171420	Cleaner & Polish
	31662	Cleaner, All-Purpose Appliance