




GAS COOKTOP

MODELS:

WCG97US0HS05 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	8286814	Head, Burner (Left Front, Left Rear, & Right Front)	13	W10758282	Screw
	W11468901	Owner's Manual				14	W10763330	Electrode, Stack (Center)
	W11466948	Quick Start Guide		8286813	Head, Burner (Right Rear)	15	W10685483	Griddle
2		Cooktop						FOLLOWING PARTS NOT ILLUSTRATED
	W111131860	Stainless		W10611434	Head, Burner (Center)			
3		Kit, Burner Cap					W10889263	Harness, Main (Switch)
	W10613386	Black	9		Grommet		W10878749	Harness, Spark Module
4		Grate Kit (Includes 2 Grates)		W10625915	Black			
	W11047085	Black	10	W10826075	Rear, Hinge-Grate (Stainless Model Only)		3400015	Screw, Grounding
5	8286863	Spring, Electrode	11	W10151347	Orifice (Left Front, Left Rear, Right Front)		W10392003	Cord, Power
6		Knobs, Cooktop					W10132200	Relief, Strain
	W11084624	Stainless		W10652711	Orifice (Right Rear)		313438	Clip, Harness
7	W10613381	Holder, Orifice (10K) (Left Front, Left Rear, Right Front)		W10672111	Orifice (1.65MM) (Center, Main)		W11173306	Kit, LP Conversion
	W10594399	Holder, Orifice (5K) (Right Rear)		W10151362	Orifice (Center, Simmer)		3801F935-51	Bracket, Tie Down
	W11168367	Holder, Orifice Stack (17K) (Center)	12	W11439331	Wiring, Electrode (Left Front, Right Front)		7101P062-60	Screw (Used for Tie Down Bracket)
				W11439332	Wiring, Electrode (Left Rear, Right Rear)		9760045	Seal, Foam
							8270P188-60	Tape, Foam

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	7	W10449143	Regulator, Pressure	16	W10566296	Tubing, Gas Burner
2	W10594395	Assembly, Pipe Manifold	8	W10594429	Bracket, Orifice Holder			(Center, Main)
3	W10594392	Valve, Single (Left Front)	9	W10475149	Module, Spark	17	W10443110	Screw
	W10594391	Valve, Single (Left Rear)	10	W10728415	Box, Burner	18	W10594430	Bracket, Orifice Holder
	W10594393	Valve, Single (Right Front)	11	W11507167	Seal, Switch Shaft			(Center)
	W10597156	Valve, Single (Right Rear)	12	W10566294	Tubing, Gas Burner (Left Front)	19	W10566297	Tubing, Gas Burner (Simmer)
	W10594389	Valve, Dual (Center)	13	W10566295	Tubing, Gas Burner (Left Rear)			(Center, Simmer)
4	8287055	Bracket, Single Valve	14	W10566299	Tubing, Gas Burner (Right Front)	20	3196537	Screw
5	8287056	Bracket, Dual Valve	15	W10566298	Tubing, Gas Burner (Right Rear)			OPTIONAL ACCESSORY PART (NOT INCLUDED)
6	W10614950	Panel, Front					W11042467	Spray, Stainless Steel Cleaning