




GAS DRYER

MODELS:

MGD5030MW1 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	W10414381	Switch, Rotary Encoder (2 Position)	20	W10414397	Switch, Rotary Encoder (3 Position)
	W11361424	Owners Manual						
	W11495041	Tech Sheet	10	688983	Screw	21	9740848	Screw
	W11466172	Quick Start Guide	11	3348629	Screw	22	343641	Screw
2	W11438904	Connector, Service Standalone	12		Top	23	W10726632	Seal, Console
				W10613389	White	24	W11486550	Harness, Upper Encoder RS
3	W11625656	Appliance Control Unit (ACU)	13	W10298336	Nut, "U"	25	W11437795	Harness, Upper Encoder
4	W10775189	Panel, Rear	14	W11328381	Knob, Large			
5	W11437794	Harness, Main	15	W11398762	Knob, Small			
6	8312709	Clip, Console	16		Assembly, Console			
7	3390663	Screw		W11576588	White			
8		Lint Screen	17	688805	Clip, Spring			
	W11538108	White	18	W10612925	Badge			
			19	W10662472	Collar, Lint Chute			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390631	Screw	18		Cabinet	34	348780	Base, Motor
2	343641	Screw		8530603	White	35	W10463967	Door, Inner
3	693995	Screw	19	98234	Clip, Ground	36		Door, Outer
4	W10841728	Seal, Spill Guard	20	8066092	Lock, Front Top		W10714510	White
5	8558833	Cover, Terminal Block	21		Panel, Front	37		Handle, Door
6	W10121316	Clamp, Motor Mount		W10664698	White		W10714516	White
7	W11598681	Panel, Rear	22	W10641296	Hinge, Top	38	W10803476	Assembly, Seal and Bearing
8	W10567345	Plug, Strike	23	685203	Clip, Felt Pad	39		Plug, Front Panel
9	W10529198	Cover, Door Catch	24	W11224630	Assembly, Door Catch		8564457	White
10	W10569603	Switch, Door	25	W10730752	Seal, Door	40	W11564940	Burner Assembly (60 Hz) (Type 1)
11	697773	Screw	26	691366	Idler Assembly	41	W10316529	Seal, Foam
12	W10869141	Cord, Power	27	342055	Screw	42	W10316619	Seal, Spill Guard
13	341029	Clamp, Pipe	28		Assembly, Hinge and Pin	43	W10529197	Bezel, Door Catch
14		Hinge Hole Cover		W10362431	White	44	W10727507	Clamp, Pipe
	W11308618	White	29	W10396029	Assembly, Motor	45	W10641295	Bracket, Rear
15	W10775448	Clip, Front Panel	30	8066184	Pulley, Motor			
16	W10779369	Foot, Dryer	31	W10131364	Belt, Drive			
17	3404162	Clamp, Motor (With Shield)	32	3400500	Bolt			
			33	W11224633	Strike, Door			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute	17	3390647	Screw	32	338906	Sensor, Radiant
2	489463	Screw	18	8066049	Funnel, Burner	33	692490	Baffle, Drum (Long)
3	3388703	Washer	19	339956	Seal	34	692526	Bearing, Ring
4	347139	Seal, Lint Chute	20	3403636	Baffle, Drum (Short)	35	W10219342	Screw
5	90767	Screw	21	8578825	Bracket, Drum Light	36	W10856781	Seal, Rear Drum
6	W10389567	Shield, Exhaust	22	90296	Nut, Push On	37	W10757750	Assembly, Drum (Complete)
7	3392519	Fuse, Thermal (91C)	23	W11398682	Bracket, Bulkhead Chute	38	3406124	Bulb, Light
8	3402841	Lens, Drum Light	24	W11032820	Bracket, Support	39	W10214261	Socket, Light
9	8577274	Thermistor	25	W10512946	Washer, Tri Ring	40	W11424720	Pad, Sensor
10	694089	Wheel, Blower	26	W10359270	Shaft, Drum Roller - Left Hand Thread			
11	8577230	Housing, Blower	27	W10359269	Shaft, Drum Roller - Right Hand Thread			
12	3398161	Clip, Heater Box						
13	343641	Screw	28	3397590	Roller, Support			
14	8530285	Box, Heater (96C)	29	348197	Washer			
15	W10754607	Thermostat, High Limit SPST (180F)	30	W10298789	Nut, Hex			
16	W11050897	Kit, Thermal Cut-Off (Includes Thermostat)	31	W10714469	Bulkhead			

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564940	Burner Assembly (60 Hz) (Type 1)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9		Orifice, Burner			
4	686590	Ignitor		234826	Type 1 (Natural)	W11581316		Kit, LP Conversion
5	W10366705	Screw	10	W11564943	Valve, Gas (60 Hz)			
6	343641	Screw	11	W10295523	Pipe Plug			
			12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10242307	Washer, Hose
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10636192	Dry Rack

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

72017 White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

350930 White

350938 Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

799344 White (Uncut)