

KitchenAid®


30" ELECTRIC BUILT-IN COOKTOP

MODELS:

KCES950KBL01 (Black)

KCES950KSS01 (Stainless)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Box, Burner (Not Serviced)	15	7101P426-60	Screw
	W11439185	Installation Instructions				16	W11177346	Top, Foam (Heat Shield)
	W11245478	Instructions, Undercounter Installation	9	W11420427	UI Assembly	17		Cover, Win Port (Not Serviced)
	W11439186	Owners Manual	10	W11110715	Rail, Horizontal	18	W11110713	Rail, Vertical
	W11238367	Diagram, Wiring	11	W11117008	Element (3200W) (Left Front)			FOLLOWING PARTS NOT ILLUSTRATED
				8273993	Element (1800W) (Left Rear)		W11110555	Harness, Main
2		Cooktop Glass Assembly		8273994	Element (1200W) (Center Front)		3192439	Seal, Limiter
	W11406992	Black		W10342780	Element (1300W) (Center Rear)		8286642	Tape, Foam
	W11432617	Stainless		W10275048	Element (3000/1400W) (Right Rear)		W11160362	Insulation, Cooktop
3		Trim, Stainless (Not Serviced)						
4	W11102056	Shield, Heat	12	W11242976	Pad, Insulation			
5	W10225448	Spring, Element	13	4455917	Bracket, Cooktop Mounting			
6	W11115981	Appliance Manager, Expansion	14	3400093	Screw			
7	W11296738	Appliance Manager, Copernicus						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10355051	Cleaner, Cooktop
	31463	Protectant, Cooktop