


KitchenAid®

Dishwasher

MODELS:

KDFE104KBL3 (Black)
KDFE104KWH3 (White)
KDFE104KPS3 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel	10		Toe Panel
	W11323304	Owners Manual		W11108979	Black		W11467733	Black
	W11650508	Energy Guide		W11110746	White		W11467726	White
	W11366143	Tech Sheet	6		Panel, Front (Includes 4, 11, 14 & 16)	11	W10692757	Barrel Nut, Front Panel
2		Arm, Hinge		W11594467	Black	12	W11438978	Screw, Black
	W11662392	Left Hand		W11594468	White		W11438977	Screw, White
	W11662370	Right Hand		W11554522	Stainless	13	W10919861	Insulation, Front Panel
3	W11377160	Cross Brace, Door	7	3400000	Screw	14	W11242133	Cover, Console
4		Handle, Pocket	8	W11364953	Screw			
	W11242122	Black	9	W11038694	Insulation, Single Layer			
	W11242123	White						


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Cap, Console	7	W11025634	Bezel, Vent	14	W11092649	Dispenser Assembly
	W11591421	Black	8	3400071	Screw	15	W11050927	Seal, Console/Door
	W11591422	White	9	W10348409	Screw	16	W11088985	Hanger, Control
2	W11387866	Jumper, UI	10	W11098822	Inner Door Assembly	17	W11527847	Vent Assembly
3	W11258418	Screw	11	W11563231	Seal, Door Bottom	18	W11397505	Fuse, In-line
4	W10711884	Screw (Long)	12	W11649438	Wiring Harness, Main (Includes Thermostat & Fuse)	19	W10348408	Screw
5	W11091934	Latch Assembly (Includes Switch)	13	W11630926	Wiring Harness, Inner Door			
6	W11648209	Control, Electronic						


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10920228	Tub Assembly (Includes Gasket)	13	W11255994	Float Switch	23	W11086088	Tub Mount, Upper Rack
2	W11226744	Base, Terminal Box	14	W11184083	Plug, Tub	24	W11362501	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
3	W11035860	Gasket, Tub	15	W11429970	Water Inlet Assembly			
4	W11429974	Nut, Water Inlet	16	W11455395	Leg, Leveling	25	3400892	Screw
5	W11090487	Strike, Latch	17	3378128	Washer, Pronged Cup	26	W11536143	Heater Element Assembly
6	W11296374	Screw	18	3400014	Screw, Grounding	27	W11132441	Terminal Block
7	W11165091	Seal, Cabinet	19	W10277003	Screw			
8	W11025993	Drip Tray	20	W11226746	Cover, Terminal Box			
9	W11025986	Funnel, Overfill Protection	21		Side Support, Tub			
10	W11025988	Funnel Extension		W10920122	Left Hand			
11	8269145	Bracket, Undercounter		W10920120	Right Hand			
12	W11165093	Cover, Tub Corner	22	W11158115	Shield, Tub Sound			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11035712	Pump Assembly	10	W11299377	Motor & Sump Assembly	20	370445	Clamp, Hose
2	W11034554	Sump with Seal (Includes 3, 4, 5, 6 & 9)	11	W11450247	Isolator, Rear Motor	21	W11163419	Bracket, Thermostat
3	W10891543	Diffuser, Inlet	12	W11250985	Hose, Pressure	22	W11193089	Thermostat (Included with Main Wiring Harness)
4	W11050773	Drain Vent Assembly	13	W10900389	Hose, Suction	23	W11025970	Fill Valve Assembly
5	9741232	Screw	14	W11035709	Motor, Drain	24	W11122851	Clamp, Hose
6	W10891547	Check Valve, Drain	15	W11131184	Hose, Drain	25	W11036159	Hose
7	W11048456	Wash Arm Assembly	16	W11175571	Disc, Diverter	26	W11036143	Clip, Hose
8	371505	Clamp, Hose	17	W11497568	Bracket, Rear Motor	27	W10466656	Clamp, Hose
9		Diverter Valve Motor (Not Serviced)	18	W11418271	Fastener	28	W11036287	Hose, Inlet
			19	W11126174	Indicator, Optical Wash	29	W11236576	Clamp, Hose


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11507999	Feed Tube Assembly	5	W11128231	Cover, Diverter	8	W10891539	Screen
2	W11039888	Retainer	6	W10892836	Retainer, Docking (2nd Level)	9	W11043437	Sprayarm, Upper
3	W11039869	Sprayarm, Third Level	7	W10891533	Filter			
4	W11043452	Manifold						


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10847875	Dishrack, Upper	6		Rack Adjuster	10	W11180178	Leveler, Adjuster Arm
2	W11441109	Track, Dishrack		W11268090	Left Hand	11	W11267699	Button, Adjuster Arm
3	W11180605	Clip, Adjuster Arm		W11268086	Right Hand	12	W11048221	Wheel
4	W11084872	Track Stop, Rear	7	W11268682	Handle, Dishrack Front	13	W11129797	Clip, Cupshelf
5	W11084874	Track Stop, Front	8	W11268681	Handle, Dishrack Rear	14	W11376395	Screw
			9	W11129799	Cupshelf Assembly	15	9741232	Screw

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525641	Dishrack, Lower	3	W11291798	Silverware Basket Assembly
2	W11133747	Wheel & Transport Assembly	4	W11267718	Lid, Silverware Basket

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4396277	Barrier Kit
	W11381654	External Drain Hose, 12 FT
	W11365011	Power Cord Kit (Straight)
	W11365014	Power Cord Kit (Right Angle)
	4396672	Strain Relief, Power Cord (Metallic)
	W10685193	Compression Hose Fitting, Water Line
	W10278635RP	Fill Hose Kit