


KitchenAid®

**FOOD WASTE DISPOSER
(1/2-Horsepower Continuous Feed)**

MODELS:

KGIC300H1

DISPOSER PARTS



DISPOSER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2	W11315643	Disposer, Complete (KGIC300H)	3	4211300	Stopper Assembly
	W10128498	Use & Care Guide				4	8174355	Kit, Installation