

KitchenAid®

**MICROWAVE
(Flush Mount)**



MODELS:

KMMF530PWH00 (White)





KMMF530PPS00 (Stainless)

KMMF530PBS00 (Black Stainless)

CONTROL PANEL PARTS




Literature Parts



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	W11706981	Assembly, Console
	W11646004	Manual, Owner's	4	W11604278	Backer, Control
	W11640274	Guide, Quick Start	5	W11616392	PCBA, Appliance Control Unit
	W11682374	Sheet, Tech			
2	W11593035	Cover, Console			


DOOR AND VENT DOOR PARTS



DOOR AND VENT DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11586596	Assembly, Vent Motor	3	W11658475	Badge
2		Door, Venting	4		Door, Complete
	W11662376	White		W11654535	White
	W11662351	Stainless		W11646020	Stainless
	W11662353	Black Stainless		W11654538	Black Stainless


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11573514	Light Strip, LED	7	W11605973	Thermostat, Convection	14	W11706994	Plate, Bottom
2	W11590185	Capacitor, High Voltage	8	W10163422	Thermistor	15	W11593189	Glass, Light
3	W11095808	Bracket, Capacitor	9	W10531156	Board, Filter	16	W11616298	Filter, Charcoal
4	W11222648	Diode, High Voltage	10	W10422951	Fuse	17	W11697097	Filter, Grease
5	W11619624	Transformer, High Voltage	11	W11586579	Plate, HVT Support			
6	W11615947	Assembly, Cooling Fan	12	W11671022	PCBA, Hood Control (MIMAS)			
			13	W11590601	Assembly, Interlock			


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11590194	Motor, Hood Fan	8	W11586583	Air Channel, Transformer	13	W10836571	Magnetron
2	W10557536	Sensor, Humidity				14	W11664266	Thermostat, Magnetron
3	W11636031	Thermostat, Cavity	9	W11659088	Air Channel, Magnetron	15	W11586580	Plate, Magnetron Support
4	W11706999	Channel, Cavity Outlet	10	W11586584	Channel, Right Hood			
5	W11634509	Baseplate,Air Guide	11	W11586581	Air Channel, Back			
6	W11405831	Capacitor, Motor	12	W10458325	Actuator			
7	W10557537	Sensor, Convection						


COOKING AND COOKWARE PARTS



COOKING AND COOKWARE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11601429	Heater, Quartz Grill	4	W11600710	Pan, Toast	7	W11658672	Motor, Stirring
2	W11593984	Assembly, Convection	5	W11600707	Basket, Air Fry	8	W11590208	Connector, Heating Plate
3	W11600706	Rack, Wire	6	W11632382	Spring, Antenna			

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11593197	Plate, Mounting
2	W10748710	Damper
3		Case, Outer
	W11633705	White
	W11593183	Black
4	W11604266	Insulation, Top Plate
5	W11604250	Insulation, Back Plate
6	W11604255	Insulation, Bottom Plate
7	W11604258	Insulation, Right Plate
8	W11340990	Cord, Power
		MISCELLANEOUS PARTS
	W11630290	Hardware, Installation
	W11630300	Kit, Bump Out (For 15in Cabinet Depth)
	W11683698	Mounting Kit, Silicone Spacers
	W11353956	Harness, Main
	W11581994	Signal Harness, HMI to Door Hinge
	W11353962	Harness, Door Hinge to ACU
	W11353973	Harness, Vent Motor to ACU
	W11353979	Harness, Cavity LED to ACU
	W11602358	Harness, MIMAS to ACU
	W11577230	Signal Harness, Door & ODM to ACU
	W11353989	Harness, Hood LED to ACU