


KitchenAid®

GAS RANGE

MODELS:

KSGB900ESS9 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	W11541188	Control, MRC2	33	W11352195	Flame Spreader (Right Rear)
	W11426594	Owners Manual	15	W10759323	Assembly, Display	34	W11352197	Flame Spreader (Left Rear)
	W11565456	Tech Sheet	16	W10558372	Bracket, Control	35	W11357364	Spreader, Flame (Fish)
	W11427468	Quick Start Guide	17		Bezel			(Center)
2		Burner Cap Kit		W10785119	Stainless (Kit of 5)	36		Cap, Burner
	W11367440	Black (Set of 3)	18	W11366282	Burner Kit (Includes Cap and Spreader)		W11346163	Black (Left Front)
3		Console			(Left Front)			FOLLOWING PARTS NOT ILLUSTRATED
	W10901118	Stainless	19	W10854253	Bumper	W11635421		Harness, Main
4	W11367105	Burner Kit (Set of 5)	20		Console, Lower Panel	W10754419		Harness, Bake and Broil
5		Cooktop		W10743276	Stainless	W10598169		Harness, Display
	W11117940	Stainless	21	W11379947	Bracket, Anti-Tip	W11635422		Harness, Bake and Warm Drawer
6	7101P485-60	Screw, Anti-Tip Kit	22	W10162253	Brace, Corner (Left)	W10575120		Harness, Keypad
7		Knob		W10162252	Brace, Corner (Right)	313438		Clip, Harness
	W10786065	Stainless (All except Left Front)	23	W10555923	Bracket, User Interface	3196520		Clip, Wire
	W10786064	Stainless (Left Front)	24	W10598048	Bracket, Console (Center)	W10580229		Wire, Ground
8		Grate Kit	25	W11355689	Keypad Shield			
	W11188538	Black	26	W11512127	Gasket, Console and Cooktop			
9	3196169	Screw	27	W10432544	Griddle			
10	W11563529	Bracket, Support (Left)	28	W10067840	Screw			
	W11563527	Bracket, Support (Right)	29	W10645947	Grommet			
11	8016P022-60	Glide, Main Top	30	9780274	Screw			
12		Endcap	31	W11348511	Flame Spreader, Stack (Left Front)			
	W10555937	Stainless (Left)			(Right Front)			
	W10555940	Stainless (Right)	32	W11352193	Flame Spreader (Right Front)			
13		Trim, Vent						
	W10577782	Stainless						


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10614920	null	20	W10686408	Kit, Reservoir (Steam Rack)	37	W10137382	Clip, Panel
2	9758701	Spacer, Door	21	W11491752	Gasket, Door	38	W10457998	Module, Spark (0 plus 2)
3	W10273002	Bracket, Oven Support	22	W10031780	Screw	39	W11350452	Spark Module
4		Panel, Side	23	W10603482	Rack, Ladder	40	W11206138	Guard, Splash
	W10162245	Black	24	W10273192	Rod, Door Switch	41	W10162254	Duct, Cooling
5	W11467246	Cooling Fan	25	W10889764	Cord, Power	42	W10162255	Duct, Cover
6	W11511828	Switch, Door	26	W10035900	Support, Oven Bottom	43	W11379356	Pan, Bake
7	W10554006	Rack, Maximum Capacity	27	W10541959	Shield, Bake	44	W10289168	Box, Burner SI
8	W10911366	Rack, Sliding	28	W11634772	Light Assembly	45	W10162257	Duct, Cooktop
9	W10289077	Receiver, Hinge	29	W10571723	Bulb, Halogen 40 Watts	46	W11379354	Cover, Back
10	W10058460	Foot, Leveling	30	W10341186	Front Foot Assembly	47	W10162249	Cover, Wire
11	W10211368	Bottom, Oven	31	W10390008	Base Rail Assembly (Left)	48	W10162241	Channel, Rear
12	W10586204	Sensor		W10390007	Base Rail Assembly (Right)	49	W10818358	Shield, Wire
13	3601P356-45	Baffle, Bake Burner				50	W10435470	Brace, Main Back
14	3196178	Screw						FOLLOWING PARTS NOT ILLUSTRATED
15	W10552502	Element, Broil Assist	32	W11320442	Gas Box Burner		4820F015-59	Insulation, Strap
16	W11040249	Assembly, Flue (Upper)	33	W11353926	Convection Assembly		W10289173	Insulation, Wrap
17	W10362924	Screw	34	W10346153	Baffle, Full Convection		W10162240	Insulation, Back
18	W10323077	Diffuser, Flame	35	W10362924	Screw		W10701082	Insulation, Vent Trim
19	3196178	Screw	36	W10554007	Rack, Steam		7111P017-60	Clamp, Wire
							3196896	Clip, Wire


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W10432224	Valve, Gas Duel (Left Front)	17	W11354862	Orifice (1.45K) (Left Front)
2	W11186513	Orifice Assembly (Left Front)		W10831590	Valve, Gas (Left Rear)		W10702888	Orifice (18K) (Left Front)
	W11186509	Orifice Assembly (Left Rear)		W10566062	Valve, Gas (Right Front)		W10849719	Orifice (5K) (Left Rear)
	W11186526	Orifice Assembly (Right Front)		W10566057	Valve, Gas (Right Rear and Center)		W10849717	Orifice (15K) (Right Front)
	W11186522	Orifice Assembly (Right Rear)					W10849714	Orifice (9.5K) (Right Rear)
	W11186518	Orifice Assembly (Center)	9	W10224921	Bracket, Aegis		W10849715	Orifice (8K) (Center)
3	W10949105	Bracket, Saddle Valve	10	W10439242	Burner, Broiler			
4	W10432252	Tube, Gas Supply	11	W10680035	Burner, Bake	18	3196178	Screw
5	W10432517	Harness, Switch Spark	12	W10554066	Valve, Regulator	19	3196385	Screw
6	W10898387	Electrode, Burner (Left Front)	13	W10324262	Igniter, Bake	20	3400016	Screw
	W11645247	Electrode, Burner (Left Rear)	14	W10306050	Tube, Broil Supply (Broiler Fitting To Valve)	21	3601P336-45	Baffle, Broil Burner
	W10669524	Electrode, Burner (Right Front and Center)	15	W10583216	Fitting, Broil Burner	22	W10827923	Electrode, Spring
	W10669523	Electrode, Burner (Right Rear)	16	W10333842	Electrode, Broil	23	W10140571	Seal, Switch Shaft
7	W11356345	Manifold Assembly						FOLLOWING PARTS NOT ILLUSTRATED
							W11397194	LP Conversion Kit (Burners)
							W10566535	LP Conversion Kit (Bake and Broil)
							W10182767	Tie, Manifold Wire


DOOR PARTS



DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10541911	Bracket, Glass Upper Handle	7	W10031780	Screw	15	W10327235	Screw
2	8533988	Screw	8	W10813140	Rail, Horizontal Support	16	W10766562	Insulation, Door
3		Assembly, Outer Door	9		Scoop, Door	17	W11379948	Glass Spacer
	W10634271	Stainless		W10613791	Black			
4	W10826568	Liner, Door	10	W10885519	Hinge, Door (Active)			
5	W11223202	Glass, Inner	11	W10319024	Washer, Door			
6		Assembly, Door Handle	12	W10813139	Rail, Vertical Support			
	W11669501	Stainless	13	W10031790	Screw			
			14	W10518672	Badge			

DRAWER PARTS



DRAWER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Drawer Handle	11	W10586204	Sensor	23	W10551011	Insulation, Bake Drawer Bottom
	W11669501	Stainless	12	W10541944	Element, Bake			FOLLOWING PARTS NOT ILLUSTRATED
2	W10757442	Drawer,Bake	13	W10551019	Cover, Side			
3	W10550987	Seal, Drawer	14	3823F017-45	Spacer, Handle			
4		Panel, Drawer Front	15	W10551018	Insulation, Drawer Front	W10550983		Insulation, Retainer Bake Drawer
	W10541954	Stainless	16	W10550982	Insulation, Drawer	W10541960		Insulation, Drawer Top
5	W11399928	Slide, Drawer (Left)	17	W10541947	Panel, Front Inner			
	W11399929	Slide, Drawer (Right)	18	W10655446	Shield, Corner			
6	W10327235	Screw	19	W10550984	Insulation, Drawer Side			
7	8533988	Screw	20	W10550985	Retainer, Side Insulation			
8	W10634260	Enclosure, Warming	21	3196560	Screw			
9	W10727084	Cover, Gas Valve	22	W10602493	Rack, Bake Drawer			
10	W10634259	Cover, Wire						

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	WA906B	Scraper, Cooktop
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10432545	Kit, Grill
	W10432019	Alt Cleaning Kit Assembly, Trim (Includes Blind Threaded Insert)
		(5/8 in)
	W10675026	Black
	W10675027	White
	W10675028	Stainless (1 1/8 in)
	W10731886	Black
	W10731885	White
	W10731887	Stainless Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless